AT&T U-verse[®] Voice and High Speed Internet Wi-Fi Gateway

selfinstallation guide

Before installation:

Do not attempt to install your services until 8pm or later on your service activation date. You can find this date on your packing slip.



Watch a how-to installation video and more!

Download and install the FREE AT&T Code Scanner on your mobile app store.

Then scan the QR code to the left with your code scanner to view U-verse self-install videos.



Get started

Before you begin:



1. Check your service activation date.

Do not attempt to install your services until **8pm or later** on the date provided to you by AT&T. This date is also located on your packing slip.

Approximate installation time: 45 minutes



2. Do you have a monitored home security system or health alarm?

If either of these apply to you, you will need an AT&T technician to install your service. Call 800.288.2020 to schedule an appointment. Additional charges will apply for professional installation services from an AT&T U-verse service technician.

In the box:

Also needed:





911 Acknowledgment form Terms of Service AT&T U-verse Voice User Guide AT&T High Speed Internet User Guide 911 stickers e _____

Your 4-digit passcode. You received a separate email or letter confirming the 4-digit passcode you designated when placing your order.

6	Service Activation Date: XXX PM on XX/XX/XXXX
	Packing slip

Images are not to scale.



1 Set up Approximate time: 10 minutes

A Connect the green data cable from the Wi-Fi Gateway's DSL Broadband port to your wall jack.



C Remove the sticker covering the Power port. Connect the Battery Backup Unit (BBU) to the Wi-Fi Gateway's Power port. Plug the BBU into a standard electrical outlet only. Wait until Step₂ before you turn on the BBU.



B Connect the yellow Ethernet cable from the Wi-Fi Gateway's Ethernet port to your computer's Ethernet port.



D Plug one end of your phone cable into the Wi-Fi Gateway's Phone Lines 1 & 2 port and the other end into a standard phone or cordless base station.



Images are not to scale.

Questions?

Go online: Visit **att.com/uversesupport**

To learn more about the benefits and features of your AT&T U-verse service, visit att.com/uversewelcome

During this time, do not unplug the BBU or green data cable, as this can permanently damage the Wi-Fi Gateway and significantly delay your Service Activation. is charging. The BBU may emit a beeping sound while charging. 3 Approximate time: 20 minutes **Open your Internet browser (e.g., Internet** Explorer, Safari, etc.): The online registration process will start automatically to help you activate your Internet and Voice services. • If the registration process does not start automatically: 1. Turn off security or firewall software, or give permission to "allow the network connection" if prompted by your browser, in order to connect to the AT&T network. 2. Enter **att.net/uverse** into your address bar. • Continue your online registration using the **4-digit** passcode you created when you placed your order it was mailed to you separately for your reference. 4 Go Wi-Fi (optional)

Write down the Wi-Fi Network Name (SSID) and Wi-Fi Password (Wireless Network Key) to configure additional Wi-Fi devices. This information is on the side of your Wi-Fi Gateway. The Wi-Fi Network Name consists of "ATT" plus the last three digits of the Wi-Fi Gateway's serial number. Be sure to record this information in the form below.

Now configure your Wi-Fi network:

- Select your Wi-Fi Network Name (SSID) from the list.
- your network.

2 Power up Approximate time: 15 minutes

• Move the switch on the back of the Battery Backup Unit (BBU) to the "on" position.

- Your Wi-Fi Gateway is now powering up. Wait up to five minutes for the Broadband and Service indicator lights to turn solid green.
- If the Broadband and Service lights do not turn solid green or continue to blink after 15 minutes, see "Having Trouble?" on the back of this guide.
- **Note:** The BBU must be charged for approximately 18 hours before it is fully operational; however installation of your service may continue while the BBU

	5
Power	
Ethernet.	
 Wreless 	L
Phone 1	
Phone 2	
= 158	
Ersetberd	
E Service	L
	Y

Wi-Fi Gateway indicator lights

$\langle \rangle$
In the International States
Orderbry me Livelarbry
And III Aspectatory
100
可

Battery Backup Unit (BBU)

Registration & Activation

- Note: You must complete both activation steps in order to use your Internet and Voice services.
- Important: You will have a dial tone after completing Step (2), but will only be able to make emergency and toll-free calls until you activate your Voice service in Step (3) (B).



To activate your Voice service to make calls: Call 1.877.377.0016 from the phone you set up in Step **(1)**, and follow the voice instructions to complete the activation.



Upon successful activation, you will hear the following: "Your telephone number XXX.XXX.XXXX has been successfully activated."

Approximate time: 10 minutes

• Go to your computer's "Wireless Network Settings" and refresh the network list.

- Enter the 10-digit Wi-Fi Password (Wireless Network Key) in the Password field to connect to

Congratulations! You should now be connected to the Internet via Wi-Fi.



Stay connected on the go!

AT&T Wi-Fi Basic is included with your AT&T U-verse High Speed Internet service, so you can access the Internet at thousands of AT&T Wi-Fi Hot Spots across the country. Visit **attwifi.com** to learn more.



Set up Voicemail from your home phone

AT&T U-verse Voicemail incorporates the latest technology to save you time and money, no matter where you are or how you communicate.

To set up your voicemail from your home phone:

- 1. Dial *98 (or dial your home phone number).
- **2.** Follow the prompts to set-up your mailbox.
- **3.** After creating your PIN, be sure to set-up your authentication code. This will allow you to reset your PIN over the phone if you forget it.

After you have set up your voice mailbox, visit **att.com/vmviewer** for the option of automatic delivery of your voicemail messages to your qualifying Wi-Fi device or computer.

By downloading the AT&T Voicemail Viewer App, you can check your voicemail messages visually, choosing the order in which you listen to them or even reading your messages as voicemail-to-text.

Manage your U-verse Phone and Voicemail features

To manage Phone Features online:

- 1. Log in to your online account at att.com/myatt
- 2. Click on HOME PHONE
- 3. Click on MANAGE FEATURES

To manage Voicemail Features online:

- 1. Log in to your online account at att.com/myatt
- 2. Click on HOME PHONE
- 3. Click on CHECK VOICEMAIL
- 4. Click on VOICEMAIL SETTINGS

For more information on managing Phone Features or Voicemail Settings go to att.com/uvfeatures

Having trouble? Here are a few common issues to check:



What is your service activation date?

Do not attempt to install your service until **8pm or later** on your service activation date. You can find this date on your packing slip.

Did you make the required activation call? You must complete activation for your AT&T U-verse Voice service to work correctly. See Step 3 B.

Still having problems? Many issues can be resolved with these simple steps:



1. Check your connections.

Check all cables and cords to ensure they are connected properly and securely.

15 SECONDS

2a. Power down, power up.

Unplug the BBU power cord from the back of the Wi-Fi Gateway. Leave the Wi-Fi Gateway unplugged for 15 seconds and plug it back in.

2b. Wait for blinking indicator lights.

You may need to wait up to two minutes for blinking indicator lights to turn solid green.

Additional U-verse information

What is your internet connection speed?

The AT&T Speed Test is available to help you gauge the performance of your online experience. Visit **att.com/speedtest** to determine the speed at which data is sent to or from your computer.

Check out the User Guides online:

Accessibility Support:

Alternate formats now available in Large Print or Braille. Call 800.288.2020 and request your guide number (ATT122090839-4) in an alternate format. Additional accessibility support:

Visit **att.com/userguides** to find an electronic version of this guide ATT122090839-4 (UV Double Play Internet + Voice) and other support information.

Go to **att.com/uverseinstall5031** to watch a how-to installation video and more.

¿Habla español?

Por favor visite **att.com/uverseguias** para ver la informacion en español. También pueden ver la siguiente guía: ATT122090839-4 (UV Double Play Internet + Voice) para más detalles.

Manage your account:

Go to **att.com/myatt** to manage your AT&T U-verse account. You can also visit **att.com/manage** to download the app.

Need more help?

Go online: Visit att.com/uversesupport Call us: Dial 800.288.2020 and ask for "U-verse technical support."

©2014 AT&T Intellectual Property. http://www.att.com/gen/privacy-policy?pid=2587 All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.

• Customers with Disabilities:

- Voice Calls: 800.288.8303
- TTY Calls: 800.536.8890
- Repair Center:
 - Voice Calls: 800.246.8464
 - TTY Calls: 800.397.3172
- Accessible Tagged PDF: Visit att.com/userguides
- Device Compatibility Feature: Compatible with any TTY/TDD devices with standard phone line

