


Let's get started.



1 Remove battery tab

Activate the battery by removing the protective tab located at the bottom of the device.

NOTE: If the tag is hard to remove, gently open the battery cover and carefully take out the battery to access the tag. Remove the protective tag from the battery contacts, then reinsert the battery securely and close the cover.



2 Power on

Power on the device by either pressing the power button or plugging the device into power.

Location is key!

Place your router on or above ground level, away from walls, electronics, and areas that can heat up.

TIP: Position it near a window, away from direct sunlight, with the back facing the window.



3 Wait

It can take up to 3 minutes for the router to boot up. You'll know it's online when the display shows your service provider and signal bars.

NOTE: If the display is dark, push the ON/OFF button.

TIP: If you have fewer than 3 bars, move the device to a location with a stronger signal.



4 Connect

You can now connect devices.

Use the Wi-Fi name and password on the bottom of the router.

Scan the documentation QR code for additional setup and product information.

Mobile App

Scan QR code to download the **Inseego Mobile™** app.



Inseego Connect Remote Management

Scan QR code to purchase **Inseego Connect** for your device.

Inseego Connect lets you configure, monitor, deploy, and control your device fleet remotely—accelerating deployments, streamlining operations and gaining visibility and control through a single pane of glass.




Product Documentation

Scan QR code for product documentation.

You can also go to:
go.inseego.com/fx4200



Empecemos.



1 Retire la pestaña de la batería

Active la batería retirando la pestaña protectora ubicada en la parte inferior del dispositivo.

NOTA: Si la etiqueta es difícil de retirar, abra con cuidado la tapa de la batería y extraiga la batería con cuidado para acceder a ella. Retire la etiqueta protectora de los contactos de la batería, vuelva a insertar la batería firmemente y cierre la tapa.

2 Encendido

Encienda el dispositivo presionando el botón de encendido o enchufándolo a la corriente.

¡La ubicación es clave! Coloque el router sobre el suelo o por encima de él, lejos de paredes, aparatos electrónicos y zonas que puedan calentarse.

CONSEJO: Colóquelo cerca de una ventana, lejos de la luz solar directa, con la parte trasera orientada hacia la ventana.

3 Espera

El router puede tardar hasta 3 minutos en iniciarse. Sabrá que está conectado cuando la pantalla muestre su proveedor de servicios y barras de señal.

NOTA: Si la pantalla está oscura, pulse el botón de encendido/apagado.

CONSEJO: Si tiene menos de 3 barras, mueva el dispositivo a un lugar con mejor señal.

4 Conectar

Ya puede conectar dispositivos.

Usa el nombre y la contraseña de Wi-Fi que se encuentran en la parte inferior del router.

Escanea el código QR de la documentación para obtener más información sobre la configuración y el producto.

Aplicación Móvil

Escanea el código QR para descargar la aplicación Inseego Mobile™.



Inseego Connect Gestión Remota

Escanee el código QR para adquirir Inseego Connect para tu dispositivo.

Inseego Connect te permite configurar, supervisar, implementar y controlar tu flota de dispositivos de forma remota, acelerando las implementaciones, optimizando las operaciones y obteniendo visibilidad y control desde un único panel.



Documentación Del Producto

Escanee el código QR para acceder a la documentación del producto.

También puedes visitar:
go.inseego.com/fx4200

