

Manufacture Code List

TV

Abex	1098
Admiral	1001, 1081, 1099
Advent	1005, 1053, 1110, 1113, 1476
Adventura	1100
Aiko	1015
Aiwa	1034
Akai	1002, 1061, 1427
Allbatron	1477
Alleron	1044
America Acton	1484
Ampro	1475
Amtron	1036
Anam	1484
Anam National	1003, 1036
AOC	1004, 1005, 1061
Apex	1085, 1111, 1119, 1163, 1256
Apple	1505
Audiovox	1036, 1367, 1484
Aventura	1483
Bang & Olufsen	1453
Belcor	1004
Bell & Howell	1001,1045
Benq	1042
Bradford	1036, 1484
Brilliant	1487
Broksonic	1114, 1121, 1382, 1383, 1484
Brokwood	1004
bvdsign	1496
Candle	1004, 1007, 1061, 1100
Carnivale	1061
Carver	1047, 1103
CCE	1490
Celebrity	1002
Centurion	1471
Citizen	1004, 1007, 1015, 1036, 1061, 1073, 1097, 1100
Clarion	1484
Colortyme	1004
Commercial Solutions	1094
Concerto	1004
Contec	1484
Contec/Cony	1011, 1012, 1036
Craig	1036, 1484
Crosley	1000, 1047, 1053, 1103, 1508
Crown	1036, 1053, 1484
CTX	1257
Curtis Mathes	1000, 1004, 1014, 1045, 1047, 1061, 1073, 1081, 1094, 1097, 1103, 1367, 1385, 1486, 1504
CXC	1036, 1484
Cytron	1456
Daewoo	1004, 1005, 1013, 1015, 1016, 1097, 1106, 1258, 1367, 1368, 1369
Daytron	1004,1097
Denon	1486
Diamondvision	1461, 1499
Dimensia	1000
Dumont	1160, 1482
Durabrand	1259, 1481, 1483, 1484, 1506
Dwin	1081, 1474
Dynatech	1004
Electroband	1002
Electrohome	1002, 1003, 1004, 1018, 1021
Emerson	1004, 1011, 1013, 1025, 1028, 1031, 1033, 1036, 1044, 1045, 1080, 1097, 1101, 1102, 1107, 1382, 1383, 1483, 1484, 1512
Envision	1004, 1061
ESA	1483
Fisher	1043, 1045
Fujitsu	1044, 1029
Funai	1036, 1044, 1384, 1483, 1484
Futuretec	1036
Futuretech	1484
Gateway	1038
GE	1000, 1003, 1004, 1008, 1021, 1048, 1049, 1063, 1068, 1094, 1144, 1164, 1224, 1367, 1380, 1381, 1385, 1386, 1493
GFM	1498
Gibraltar	1061, 1160, 1482
Go Video	1480
Goldstar	1004, 1005, 1011, 1018, 1050, 1061, 1090, 1091, 1097, 1098, 1400, 1401
GPX	1320
Grunpy	1036, 1044, 1484
Haier	1481, 1491
Hallmark	1004
Harley Davidson	1384
Harman/Kardon	1103
Harvard	1036, 1484
Hauppauge	1503
Haverly	1081
Hello Kitty	1367
Hewlett Packard	1509
Hisense	1112
Hitachi	1004, 1011, 1012, 1051, 1052, 1084, 1086, 1087, 1102, 1225, 1384, 1486
HP	1408, 1509
Humax	1374
Hyundai	1479
Ilo	1457
IMA	1036
Infinity	1047, 1053, 1103
Insignia	1507
Inteq	1482
Janeil	1100
JBL	1047, 1053, 1103
JC Penney	1000, 1004, 1005, 1007, 1012, 1021, 1048, 1049, 1058, 1063, 1068, 1072, 1073, 1075, 1097, 1098
JCB	1002
Jensen	1004, 1232, 1285, 1376
JVC	1011, 1012, 1026, 1049, 1052, 1054, 1055, 1080, 1092, 1117, 1131, 1235, 1288, 1299
Kawasho	1002, 1004
KEC	1484
Kenwood	1004, 1018, 1061
Kliss NovaTeam	1036, 1056, 1057, 1100
KTV	1036, 1061, 1097, 1101, 1484, 1490
LG	1005, 1396, 1397, 1398, 1399, 1402, 1403, 1404, 1405, 1501
Lloyd's	1036
Loewe	1053
Logik	1001
Luxman	1004
LXMI	1000, 1004, 1045, 1047, 1053, 1058, 1068, 1075, 1085, 1094, 1103
Magnavox	1004, 1007, 1018, 1047, 1053, 1056, 1057, 1059, 1060, 1061, 1083, 1103, 1110, 1147, 1228, 1260, 1300, 1301, 1302, 1321, 1326, 1339, 1366, 1384, 1387
Magnin	1380
Majestic	1001
Marantz	1004, 1047, 1051, 1053, 1061, 1103
Matsushita	1485
Media Center	1408
Megatron	1004, 1051, 1486
Memorex	1001, 1004, 1005, 1022, 1045
MGA	1004, 1005, 1018, 1021, 1061, 1380
Midland	1049, 1068, 1094, 1097, 1098, 1160, 1482
Minutz	1048
Mitsubishi	1004, 1005, 1018, 1021, 1081, 1381
Monivision	1477
Motogony Ward	1001
Motorola	1003, 1081, 1099
MTC	1004, 1005, 1061, 1073,
Multitech	1036, 1484, 1490
Multivision	1472
NAD	1004, 1058, 1075, 1085
NEC	1003, 1004, 1005, 1061
Net-TV	1040
Nikko	1004, 1015, 1061
Norcent	1217
NTC	1015
Olevia	1420
Omwa	1036, 1484
Oppo	1497
Optimus	1485
Optonica	1064, 1081, 1099
Orion	1023, 1033, 1107, 1382, 1383, 1511
Panasonic	1003, 1010, 1049, 1053, 1096, 1123, 1152, 1231, 1289, 1292, 1295, 1303, 1304, 1305, 1306, 1385, 1485, 1500, 1503
Penney	1061, 1085, 1094, 1380, 1385
Philio	1003, 1004, 1005, 1007, 1011, 1018, 1047, 1053, 1056, 1057, 1059, 1061, 1103
Philips	1003, 1004, 1007, 1011, 1017, 1018, 1047, 1053, 1056, 1057, 1059, 1060, 1063, 1103, 1110, 1126, 1129, 1148, 1155, 1238, 1263, 1264, 1265, 1290, 1291, 1307, 1308, 1309, 1337, 1389
Philps/Magnava	1260, 1264, 1265, 1266
Pilot	1061, 1097
Pioneer	1004, 1102
Polaroid	1285, 1371, 1458, 1502
Portland	1004, 1005, 1015, 1097
Price Club	1073
Prima	1113, 1476
Prism	1049
Proscan	1000, 1008, 1068, 1094, 1108
Proton	1004, 1011
Protron	1494
Pulsar	1160, 1482
Pulser	1004
Quasar	1003, 1039, 1049, 1096, 1165, 1166, 1385, 1485,
Radio Shack	1000, 1045, 1061, 1094, 1098, 1384, 1484
Radio Shack/Realis	1004, 1011, 1036, 1045, 1064, 1097, 1098
RCA	1000, 1003, 1004, 1005, 1008, 1018, 1090, 1091, 1097, 1098, 1400, 1401, 1070, 1071, 1082, 1094, 1102, 1104, 1106, 1108, 1115, 1151, 1162, 1167, 1168, 1268, 1269, 1270, 1271, 1310, 1355, 1359, 1370, 1373, 1379, 1380, 1381, 1385, 1386
Realistic	1061, 1484
Runco	1061, 1160, 1482
Sampo	1004, 1061, 1097, 1098, 1120
Samsung	1004, 1005, 1011, 1014, 1018, 1019, 1061, 1072, 1073, 1074, 1097, 1098, 1156, 1161, 1297, 1314, 1323, 1360, 1363, 1364, 1490, 1492, 1510
Philips	1126, 1129, 1236, 1237, 1239, 1261, 1334, 1351, 1390, 1411
Pioneer	1035, 1195, 1240, 1335, 1469, 1470, 1384
Polaroid	1262, 1391, 1392, 1393, 1396, 1431, 1440
Proscan	1000
Protron	1430
Proview	1407
RCA	1143, 1196, 1241, 1242
Sampo	1038, 1243
Sharp	1085, 1094, 1103, 1105, 1384, 1483
Sheng Chia	1081
Shogun	1004
Signature	1001
Simpson	1007
Sony	1002, 1109, 1137, 1201, 1202, 1249, 1272, 1275, 1276, 1277, 1278, 1317, 1356, 1384, 1388
Soundesign	1004, 1007, 1036, 1044, 1484
Squareview	1105, 1483
SSS	1036, 1484
Starlite	1036, 1484
Studio Experience	1477
Superscan	1081, 1498
Supre-Macy	1100
Supreme	1002
SVL	1491
Sylvania	1004, 1007, 1018, 1027, 1047, 1056, 1057, 1059, 1060, 1061, 1103, 1124, 1145, 1150, 1153, 1279, 1296, 1387, 1464, 1483
Symphonic	1024, 1031, 1036, 1105, 1280, 1384, 1483, 1484
Syntax	1488
Tandy	1081, 1099
Tashiko	1058
Tatung	1003
Technics	1049, 1485
Techeview	1478
Television	1004, 1049
Teknika	1001, 1004, 1005, 1007, 1012, 1015, 1036, 1044, 1047, 1060, 1073, 1096, 1097, 1103, 1111, 1484
Telecapcion	1473
Tera	1004, 1011
Thomas	1384
TMK	1004
ILG	1255, 2371
Toshiba	1006, 1045, 1058, 1073, 1079, 1085, 1093, 1116, 1154, 1158, 1159, 1175, 1252, 1267, 1281, 1282, 1283, 1284, 1286, 1293, 1294, 1313, 1315, 1319, 1338, 1377, 1473
Totevision	1097
Universal	1048, 1063
V inc.	1489
Victor	1055
Vidikon	1047, 1103
Vidtech	1004, 1005
Visioning	1361, 1489, 1495
Viking	1100
Vizio	1489
Wards	1000, 1001, 1004, 1005, 1031, 1044, 1047, 1048, 1053, 1056, 1057, 1059, 1060, 1061, 1063, 1064, 1103, 1118
Waycon	1085
Westinghouse	1367, 1489
White Westinghouse	1013
Yamaha	1004, 1005, 1018, 1061
Zenith	1001, 1089, 1118, 1125, 1161, 1287, 1357, 1382, 1383, 1384, 1482

HDTV

Acer	1041, 1192
Akai	1427, 1432
Apex	1088
Astar	1434
Audiovox	1455
Axion	1459
Benq	1136
Daewoo	1298
Daewoo	1382
Emerson	1383
Element	1431
Emerson	1468
Emprex	1438
Epson	1422, 1451
Fujitsu	1029
Gateway	1038, 1449
Hewlett Packard	1419, 1444, 1445, 1452
Hitachi	1030, 1132, 1133, 1134, 1191, 1208, 1209, 1210, 1211, 1212, 1276, 1322, 1324, 1328, 1344, 1447
HP	1419, 1445, 1452
Ilo	1412, 1435, 1436
Infocus	1450
Initial	1457
Insignia	1437
JVC	1130, 1131, 1227
LG	1343, 1346, 1396
Magnavox	1329, 1358, 1372, 1414
Philips	1126, 1129, 1236, 1237, 1239, 1261, 1334, 1351, 1390, 1411
Pioneer	1035, 1195, 1240, 1335, 1469, 1470, 1384
Polaroid	1262, 1391, 1392, 1393, 1396, 1431, 1440
Proscan	1000
Protron	1430
Proview	1407
RCA	1143, 1196, 1241, 1242
Sampo	1038, 1243
Samsung	1161, 1089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095
Toshiba	1006, 3096
Samsung	1161, 3089
Sansui	1382, 3213
Sony	1380, 3201
Sharp	1311, 3163
Sanyo	1380, 3201
Sylvania	1145, 3095