

<b>AT&amp;T smartphones that support Wi-Fi Calling</b>		
<b>Manufacturer</b>	<b>Phone model</b>	
<b>Apple</b>	<ul style="list-style-type: none"> <li>• iPhone XR</li> <li>• iPhone XS</li> <li>• iPhone XS Max</li> <li>• iPhone X</li> <li>• iPhone 8</li> <li>• iPhone 8 Plus</li> </ul>	<ul style="list-style-type: none"> <li>• iPhone 7</li> <li>• iPhone 7 Plus</li> <li>• iPhone SE</li> <li>• iPhone 6S</li> <li>• iPhone 6S Plus</li> <li>• iPhone 6</li> <li>• iPhone 6 Plus</li> </ul>
<b>LG</b>	<ul style="list-style-type: none"> <li>• LG G8 (model #: LM-G820UM)</li> <li>• LG G6</li> <li>• G Vista 2</li> <li>• Phoenix 2<sup>1</sup></li> <li>• Phoenix 3<sup>1</sup></li> <li>• Phoenix 4<sup>1</sup></li> <li>• Phoenix Plus<sup>1</sup></li> <li>• V30</li> <li>• V20</li> </ul>	<ul style="list-style-type: none"> <li>• V35 ThinQ</li> <li>• V40Q</li> <li>• V10<sup>1</sup></li> <li>• LG G5<sup>1</sup></li> <li>• LG K20</li> <li>• LG K10</li> <li>• LG G4<sup>1</sup></li> <li>• LG X venture</li> <li>• LG Stylo 4+</li> </ul>
<b>Samsung</b>	<ul style="list-style-type: none"> <li>• Galaxy A6 (model #: SM-A600A)</li> <li>• Galaxy Express Prime 3<sup>1</sup></li> <li>• Galaxy Express Prime 2<sup>1</sup></li> <li>• Galaxy Express Prime<sup>1</sup></li> <li>• Galaxy J7 (2017 &amp; newer)</li> <li>• Galaxy J3 (2016 &amp; newer+)<sup>1</sup></li> <li>• Galaxy J2 Dash (model #: SM-J260A)</li> <li>• Galaxy A10e (model # SM-A102U)</li> <li>• Galaxy S10e (model #: SM-G970U)</li> <li>• Galaxy S10 (model #: SM-G973U)</li> <li>• Galaxy S10+ (model #: SM-G975U)</li> <li>• Galaxy S10 5G (model #: SM-977U)</li> <li>• Galaxy S9 (model #: SM-G960U)</li> <li>• Galaxy S9+ (model #: SM-965U)</li> <li>• Galaxy S8 (model #: SM-950U)</li> <li>• Galaxy S8+ (model #: SM-955U)</li> </ul>	<ul style="list-style-type: none"> <li>• Galaxy S8 Active</li> <li>• Galaxy S7<sup>1</sup></li> <li>• Galaxy S7 active<sup>1</sup></li> <li>• Galaxy S7 edge<sup>1</sup></li> <li>• Galaxy S6<sup>1</sup></li> <li>• Galaxy S6 active<sup>1</sup></li> <li>• Galaxy S6 edge<sup>1</sup></li> <li>• Galaxy S6 edge+</li> <li>• Galaxy S5<sup>1</sup></li> <li>• Galaxy S5 active<sup>1</sup></li> <li>• Note10+</li> <li>• Note10</li> <li>• Note9</li> <li>• Note8 (model #: SM-N950U)</li> <li>• Note5<sup>1</sup></li> <li>• Note4<sup>1</sup></li> <li>• Note Edge<sup>1</sup></li> </ul>
<b>ZTE</b>	<ul style="list-style-type: none"> <li>• Blade Spark<sup>1</sup></li> <li>• Maven 3<sup>1</sup></li> </ul>	
<b>Huawei</b>	<ul style="list-style-type: none"> <li>• Ascend</li> <li>• Ascend XT2</li> </ul>	
<b>Motorola</b>	<ul style="list-style-type: none"> <li>• G6 Play</li> </ul>	

<b>Kyocera</b>	<ul style="list-style-type: none"> <li>• DuraForce Pro 2 (model #: E6920)</li> </ul>
<b>Sonim</b>	<ul style="list-style-type: none"> <li>• XP8 (model #: XP8800)</li> </ul>
<sup>1</sup> Indicates Android devices requiring most recent software update to enable Wi-Fi Calling	

<b>Non-AT&amp;T smartphones that support Wi-Fi Calling</b>	
<b>Manufacturer</b>	<b>Phone model</b>
<b>Apple (iOS 9.3 or higher)</b>	<ul style="list-style-type: none"> <li>• iPhone 6 - A1586</li> <li>• iPhone 6 Plus - A1524</li> <li>• iPhone 6s - A1688</li> <li>• iPhone 6s Plus - A1687</li> <li>• iPhone 6s - A1700</li> <li>• iPhone 6s Plus - A1699</li> <li>• iPhone 7 or iPhone 7 Plus</li> <li>• iPhone 8 or iPhone 8 Plus</li> <li>• iPhone X (models A1865 &amp; A1901)</li> </ul>
<b>Google</b>	<ul style="list-style-type: none"> <li>• Google Pixel 3 (model #: G013A)</li> <li>• Google Pixel 3 XL (model #G013C)</li> <li>• Google Pixel 3a (model #: G020G)</li> <li>• Google Pixel 3a XL (model #: G020C)</li> </ul>
<b>LG</b>	<ul style="list-style-type: none"> <li>• LG V35 (model #: LM-V350ULM)</li> <li>• LG G7 (model #: LMG710ULM)</li> </ul>