



Adding a second Wireless TV Receiver

A Complete the installation of the first TV Receiver.

B Repeat steps 2 and 3 in this guide with the second TV Receiver.



Visit: att.com/wirelesstv
or scan the QR code



Download and install the free AT&T Code Scanner on your mobile phone at <http://scan.mobi> or your app store.

From there you can:

- View help videos
- Chat online with a technician
- Easily find troubleshooting information and user guides
- Learn how to return this product

If that doesn't do it, give us a call at 1.800.288.2020 and ask for "U-verse technical support." We can help you with that!

Questions?

Go online: Visit att.com/uversesupport.

To learn more about the benefits and features of your AT&T U-verse service, visit att.com/u-verse/newcustomer.

¿Habla español? Por favor visite att.com/uverseguias para ver la informacion en Español. También puede ver la siguiente guía: ATT110900769-6 (Wireless TV Receiver) para más detalles.

Important legal information regarding your Wireless Receiver: Additional fee(s) may apply. Wireless from the Wireless Access Point to the Wireless Receiver; power outlet and separate connection of Wireless Receiver to TV is required. For residential use in a single household only. Limit two wireless receivers per household. Actual range of wireless signal will vary and may be limited by several factors including, but not limited to, electromagnetic interference, home construction material, obstructions, and other environmental factors. The installation and use of the Wireless Receiver is subject to the AT&T U-verse Terms of Service that can be found at att.com/u-verse/att-terms-of-service.jsp.



AT&T U-verse® TV Wireless TV Receiver

self-
installation
guide

Important!

Do not attempt to install your new receiver until 8pm or later on your service activation date. You can find this date on your packing slip.



Packing slip



Ready to install your AT&T U-verse Wireless TV Receiver?


Average installation time: 20 minutes

Let's get started


What's in the box?

To install your Receiver, you will need:


AT&T U-verse Wireless TV Receiver




AT&T U-verse Wireless TV Receiver power cord (2 parts)




Wireless Access Point




Wireless Access Point power cord



Remote control




Ethernet cable



Not Sure?
Check the
sticker.

What else do you need?

Your existing Wi-Fi Gateway
(actual model may vary)



Your TV's
user manual



HDMI, component, composite,
or coaxial cabling (not included)



Note: Additional cable(s) (HDMI, RCA, Coaxial, etc.) that connects TV with AT&T U-verse Wireless Receiver not included.




ATT110900769-6

1. Set up

First you need to connect your existing Wi-Fi Gateway to the Wireless Access Point.
NOTE: If you are adding a Second Wireless TV Receiver, skip this step and go to Step 2.

- A Connect the Wireless Access Point to your existing Wi-Fi Gateway using the yellow Ethernet cable.
- B Use the power cord to plug the Wireless Access Point into a working electrical outlet.




Remember:
Make sure you have an open Ethernet port on your existing Wi-Fi Gateway, and be sure to leave existing cables plugged in. No open port? You'll need to purchase an Ethernet hub with additional ports.

2. Power up

The next step is to connect your Wireless Receiver to your TV.


- A Connect the receiver to your TV with an HDMI cable (not included). You may also use RCA or Coaxial cables.
- B Power up your TV and go to the Input Source screen. Your TV manufacturer's remote control may have an Input button that will take you there. Select the Source you used in Step 2A. For instance, if you used an HDMI cable, select HDMI.
- C Put the two-part power cord together. Then use it to plug the receiver into an electrical outlet and it will power up automatically. After about a minute, you'll receive additional onscreen instructions.



3. Pair up

Now let's get your Wireless TV Receiver and Wireless Access Point talking to each other. Follow the instructions on your TV screen.



- A On the front of your new receiver, press the **OK** button.



Your TV screen should look like this.


Note: Pairing occurs quickly. To ensure you have proper signal strength, there should be at least three LED green bars lit up on the receiver.

- B Press the Wi-Fi Protected Setup (WPS) button on the front of the Wireless Access Point, and you'll see a fast-blinking LED light up on the unit.



Your TV screen should look like this.

- C When you see a green antenna icon on your TV screen or a green LED on the front of your receiver, you've paired successfully. It may then take a few more minutes before live TV appears.



Your TV screen should look like this.

Nicely done. The hard part is over – now it's time to enjoy U-verse TV.

Having trouble?

If you see a red antenna:

- 1 Disconnect your Wireless TV Receiver from its current location.
- 2 Plug the receiver into a power cord that is closer to the Wireless Access Point.
- 3 Give it a minute and then repeat Steps 3A and 3B.



Remote control information



New AT&T U-verse customers or current customers adding a new receiver will need to program the new remote control. Programming instructions are available online at att.com/wirelessTV and in the remote control user guide packaged with the remote control.