

Manufacture Code List

Jump to ...

[TV](#)

[HDTV](#)

[TV DVD COMBO](#)

[TV DVD TUNER COMBO](#)

[TV VCR COMBO](#)

[TV DVD VCR COMBO](#)

[TV VCR TUNER COMBO](#)

[TV VCR DVD TUNER COMBO](#)

[TV RECEIVER](#)

[DVD](#)

[DVD TUNER COMBO](#)

[DVD VCR COMBO](#)

[VCR](#)

[HTIB](#)

[REC TUN](#)

[AMPLIFIER](#)

TV

Abex 1098
Admiral 1001, 1081, 1099
Advent 1005, 1053, 1110, 1113, 1476
Adventura 1100
Aiko 1015
Aiwa 1034
Akai 1002, 1061, 1427
Albatron 1477
Alleron 1044
America Action 1484
Ampro 1475
Amtron 1036
Anam 1484
Anam National 1003, 1036
AOC 1004, 1005, 1061
Apex 1085, 1111, 1119, 1163, 1256
Apple 1505
Audiovox 1036, 1367, 1484
Aventura 1483
Bang & Olufsen 1453
Belcor 1004
Bell & Howell 1001, 1045
Benq 1042
Bradford 1036, 1484
Brilliant 1487
Broksonic 1114, 1121, 1382, 1383, 1484
Brokwood 1004
byd:sign 1496
Candle 1004, 1007, 1061, 1100
Carnivale 1061
Carver 1047, 1103
CCE 1490
Celebrity 1002
Centurion 1471
Citizen 1004, 1007, 1015, 1036, 1061, 1073, 1097, 1100
Clarion 1484
Colortyme 1004
Commercial Solutions 1094
Concerto 1004
Contec 1484
Contec/Cony 1011, 1012, 1036
Craig 1036, 1484
Crosley 1000, 1047, 1053, 1103, 1508

Crown 1036, 1053, 1484
CTX 1257
Curtis Mathes 1000, 1004, 1014, 1045, 1047, 1061, 1073, 1081,
1094, 1097, 1103, 1367, 1385, 1486, 1504
CXC 1036, 1484
Cytron 1456
Daewoo 1004, 1005, 1013, 1015, 1016, 1097, 1106, 1258, 1367,
1368, 1369
Daytron 1004, 1097
Denon 1486
DiamondVision 1461, 1499
Dimensia 1000
Dumont 1160, 1482
Durabrand 1259, 1481, 1483, 1484, 1506
Dwin 1081, 1474
Dynatech 1004
Electroband 1002
Electrohome 1002, 1003, 1004, 1018, 1021
Emerson 1004, 1011, 1013, 1025, 1028, 1031, 1033, 1036, 1044,
1045, 1080, 1097, 1101, 1102, 1107, 1382, 1383, 1483, 1484, 1512
Envision 1004, 1061
ESA 1483
Fisher 1043, 1045
Fujitsu 1044, 1029
Funai 1036, 1044, 1384, 1483, 1484
Futuretec 1036
Futuretech 1484
Gateway 1038
GE 1000, 1003, 1004, 1008, 1021, 1048, 1049, 1063, 1068, 1094,
1144, 1164, 1224, 1367, 1380, 1381, 1385, 1386, 1493
GFM 1498
Gibraltar 1061, 1160, 1482
Go Video 1480
Goldstar 1004, 1005, 1011, 1018, 1050, 1061, 1090, 1091, 1097,
1098, 1400, 1401
GPX, 1320
Grumpy 1036, 1044, 1484
Haier 1481, 1491
Hallmark 1004
Harley Davidson 1384
Harman/Kardon 1103
Harvard 1036, 1484
Hauppauge 1503
Havermy 1081
Hello Kitty 1367
Hewlett Packard 1509
Hisense 1112
Hitachi 1004, 1011, 1012, 1051, 1052, 1084, 1086, 1087, 1102,
1225, 1384, 1486
HP 1408, 1509
Humax 1374
Hyundai 1479
Ilo 1457
IMA 1036
Infinity 1047, 1053, 1103
Insignia 1507
Inteq 1482
Janeil 1100
JBL 1047, 1053, 1103
JC Penney 1000, 1004, 1005, 1007, 1012, 1021, 1048, 1049, 1058,
1063, 1068, 1072, 1073, 1075, 1097, 1098
JCB 1002
Jensen 1004, 1232, 1285, 1376
JVC 1011, 1012, 1026, 1049, 1052, 1054, 1055, 1080, 1092, 1117,
1131, 1235, 1288, 1299
Kawasho 1002, 1004
KEC 1484
Kenwood 1004, 1018, 1061
Kloss Novabeam 1036, 1056, 1057, 1100
KTV 1036, 1061, 1097, 1101, 1484, 1490,
LG 1005, 1396, 1397, 1398, 1399, 1402, 1403, 1404, 1405, 1501
Lloyd's 1384
Loewe 1053
Logik 1001
Luxman 1004
LXI 1000, 1004, 1045, 1047, 1053, 1058, 1068, 1075, 1085, 1094,
1103
Magnavox 1004, 1007, 1018, 1047, 1053, 1056, 1057, 1059, 1060,
1061, 1083, 1103, 1110, 1147, 1228, 1260, 1300, 1301, 1302, 1321,
1326, 1339, 1366, 1384, 1387

Magnin 1380
 Majestic 1001
 Marantz 1004, 1047, 1051, 1053, 1061, 1103
 Matsushita 1485
 Media Center 1408
 Megatron 1004, 1051, 1486
 Memorex 1001, 1004, 1005, 1022, 1045
 MGA 1004, 1005, 1018, 1021, 1061, 1380
 Midland 1049, 1068, 1094, 1097, 1098, 1160, 1482
 Minutz 1048
 Mitsubishi 1004, 1005, 1018, 1021, 1081, 1381
 Monivision 1477
 Montgomery Ward 1001
 Motorola 1003, 1081, 1099
 MTC 1004, 1005, 1061, 1073,
 Multitech 1036, 1484, 1490
 Multivision 1472
 NAD 1004, 1058, 1075, 1085
 NEC 1003, 1004, 1005, 1061
 Net-Tv 1040
 Nikko 1004, 1015, 1061
 Norcent 1217
 NTC 1015
 Olevia 1420
 Onwa 1036, 1484
 Oppo 1497
 Optimus 1485
 Optonica 1064, 1081, 1099
 Orion 1023, 1033, 1107, 1382, 1383, 1511
 Panasonic 1003, 1010, 1049, 1053, 1096, 1123, 1152, 1231, 1289,
 1292, 1295, 1303, 1304, 1305, 1306, 1385, 1485, 1500
 Penney 1061, 1085, 1094, 1380, 1385
 Philco 1003, 1004, 1005, 1007, 1011, 1018, 1047, 1053, 1056, 1057,
 1059, 1061, 1103
 Philips 1003, 1004, 1007, 1011, 1017, 1018, 1047, 1053, 1056, 1057,
 1059, 1060, 1063, 1103, 1110, 1126, 1129, 1148, 1155, 1238, 1263,
 1264, 1265, 1290, 1291, 1307, 1308, 1309, 1337, 1389
 Philips Magnavox 1260, 1264, 1265, 1266
 Pilot 1061, 1097
 Pioneer 1004, 1102
 Polaroid 1285, 1371, 1458, 1502
 Portland 1004, 1005, 1015, 1097
 Price Club 1073
 Prima 1113, 1476
 Prism 1049
 Proscan 1000, 1008, 1068, 1094, 1108
 Proton 1004, 1011
 Protron 1494
 Pulsar 1160, 1482
 Pulsar 1004
 Quasar 1003, 1039, 1049, 1096, 1165, 1166, 1385, 1485,
 Radio Shack 1000, 1045, 1061, 1094, 1098, 1384, 1484
 Radio Shack/Realistic 1004, 1011, 1036, 1045, 1064, 1097, 1098
 RCA 1000, 1003, 1004, 1005, 1008, 1018, 1049, 1065, 1066, 1067,
 1068, 1069, 1070, 1071, 1082, 1094, 1102, 1104, 1106, 1108, 1115,
 1151, 1162, 1167, 1168, 1268, 1269, 1270, 1271, 1310, 1355, 1359,
 1370, 1373, 1379, 1380, 1381, 1385, 1386
 Realistic 1061, 1484
 Runco 1061, 1160, 1482
 Sampo 1004, 1061, 1097, 1098, 1120
 Samsung 1004, 1005, 1011, 1014, 1018, 1019, 1061, 1072, 1073,
 1074, 1097, 1098, 1156, 1161, 1297, 1314, 1323, 1360, 1363, 1364,
 1490, 1492, 1510
 Sansui 1023, 1107, 1122, 1273, 1382, 1383, 1384
 Sanyo 1045, 1062, 1095, 1380,
 Sceptre 1365
 Scotch 1004
 Scott 1004, 1011, 1033, 1036, 1044, 1484
 Sears 1000, 1004, 1012, 1018, 1044, 1045, 1047, 1055, 1058, 1068,
 1075, 1076, 1085, 1094, 1103, 1105, 1384, 1483
 Sharp 1004, 1009, 1011, 1025, 1064, 1077, 1078, 1081, 1097, 1099,
 1153, 1157, 1274, 1298, 1311, 1312, 1362, 1375, 1378
 Sheng Chia 1081
 Shogun 1004
 Signature 1001
 Simpson 1007
 Sony 1002, 1109, 1137, 1201, 1202, 1249, 1272, 1275, 1276, 1277,
 1278, 1317, 1356, 1384, 1388
 Soundesign 1004, 1007, 1036, 1044, 1484
 Squareview 1105, 1483
 SSS 1036, 1484
 Starlite 1036, 1484
 Studio Experience 1477
 Superscan 1081, 1498
 Supre-Macy 1100
 Supreme 1002
 SVA 1491
 Sylvania 1004, 1007, 1018, 1027, 1047, 1056, 1057, 1059, 1060,
 1061, 1103, 1124, 1145, 1150, 1153, 1279, 1296, 1387, 1464, 1483
 Symphonic 1024, 1031, 1036, 1105, 1280, 1384, 1483, 1484
 Syntax 1488
 Tandy 1081, 1099
 Tashiko 1058
 Tatung 1003
 Technics 1049, 1485
 Techview 1478
 Techwood 1004, 1049
 Teknika 1001, 1004, 1005, 1007, 1012, 1015, 1036, 1044, 1047,
 1060, 1073, 1096, 1097, 1103, 1111, 1484
 Telecaption 1473
 Tera 1004, 1011
 Thomas 1384
 TMK 1004
 TNCi 1482
 Toshiba 1006, 1045, 1058, 1073, 1079, 1085, 1093, 1116, 1154,
 1158, 1159, 1175, 1252, 1267, 1281, 1282, 1283, 1284, 1286, 1293,
 1294, 1313, 1315, 1319, 1338, 1377, 1473
 Totevision 1097
 Universal 1048, 1063
 V Inc. 1489
 Vector Research 1061
 Victor 1055
 Vidikron 1047, 1103
 Vidtech 1004, 1005
 Viewsonic 1361, 1489, 1495
 Viking 1100
 Vizio 1489
 Wards 1000, 1001, 1004, 1005, 1031, 1044, 1047, 1048, 1053, 1056,
 1057, 1059, 1060, 1061, 1063, 1064, 1103, 1118
 Waycon 1085
 Westinghouse 1367, 1489
 White Westinghouse 1013
 Yamaha 1004, 1005, 1018, 1061
 Zenith 1001, 1089, 1118, 1125, 1161, 1287, 1357, 1382, 1383, 1384,
 1482

HDTV

Acer 1041, 1192
 Akai 1427, 1432
 Apex 1088
 Astar 1434
 Audiovox 1455
 Axion 1459
 Benq 1136
 Coby 1460
 Daewoo 1135
 Dell 1141, 1142, 1146, 1394, 1395, 1409
 Element 1431
 Emerson 1468
 Emprex 1438
 Epson 1422, 1451
 Fujitsu 1029
 Gateway 1038, 1449
 Hewlett Packard 1419, 1444, 1445, 1452
 Hitachi 1030, 1132, 1133, 1134, 1191, 1208, 1209, 1210, 1211,
 1212, 1226, 1322, 1324, 1328, 1344, 1447
 HP 1419, 1445, 1452
 Ilo 1412, 1435, 1436
 InFocus 1450
 Initial 1457
 Insignia 1437
 JVC 1130, 1131, 1227
 LG 1343, 1346, 1396
 Magnavox 1329, 1358, 1372, 1414
 Maxent 1424

Mintek 1457
Mitsubishi 1032, 1213, 1229, 1230, 1448
NEC 1193, 1423
NET-TV 1040
Olevia 1406, 1418, 1421, 1462
Panasonic 1140, 1169, 1170, 1194, 1233, 1234, 1331, 1336, 1410, 1417, 1442, 1466
Philips 1126, 1129, 1236, 1237, 1239, 1261, 1334, 1351, 1390, 1411
Pioneer 1035, 1195, 1240, 1335, 1469, 1470,
Polaroid 1262, 1391, 1392, 1393, 1396, 1431, 1440
Proscan 1000
Protron 1430
Proview 1407
RCA 1143, 1196, 1241, 1242
Sampo 1038, 1243
Samsung 1019, 1171, 1172, 1173, 1174, 1175, 1197, 1198, 1199, 1200, 1245, 1246, 1325, 1327, 1352, 1354, 1443
Sceptre 1467
Scott 1428
Sharp 1138, 1176, 1177, 1214, 1244, 1247, 1248, 1348, 1350, 1415, 1416
Sony 1037, 1128, 1137, 1178, 1215, 1216, 1218, 1219, 1220, 1221, 1250, 1251, 1316, 1318, 1330, 1347, 1413
SVA 1446
Sylvania 1046, 1465
Syntax 1418
Syntax-Brilliant 1418
Tatung 1426
Toshiba 1127, 1179, 1203, 1204, 1222, 1223, 1332, 1340, 1341, 1345, 1353
Trutech 1425
Viewsonic 1038, 1149, 1180, 1181, 1182, 1183, 1184, 1185, 1186, 1187, 1188, 1189, 1190, 1205, 1206, 1441,
Viore 1435
Vizio 1429, 1433, 1439
Westinghouse 1454
Zenith 1020, 1139, 1207, 1253, 1255, 1333, 1342, 1349

TV DVD COMBO

TV Code DVD Code
Akai 1427 2378
Apex 1163 2095
Axion 1459 2379
Bang & Olufsen 1453 2370
Broksonic 1114 2053
Coby 1460 2380
Cytron 1456 2374
DiamondVision 1461 2382
GFM 1498 2263
Hitachi 1226 2240
Ilo 1457 2375
Initial 1457 2381
JVC 1288 2206
LG 1255 2371
Mintek 1457 2381
Oppo 1497 2432
Panasonic 1289 2207
Philips 1290 2208
1291 2209
1337 2243
Polaroid 1458 2377
1502 2265
1440 2409
RCA 1115 2063
1162 2099
1379 2289
Sansui 1122 2071
Sylvania 1150 2092
1464 2408
1465 2260
Toshiba 1116 2054
1293 2210
1294 2210
1345 2231
Westinghouse 1454 2372

TV DVD TUNER COMBO

TV Code DVD Code VCR Code
Audiovox 1455 2373 5152

TV VCR COMBO

DVD Code VCR Code
Broksonic 1121 3081
1382 3213
1383 3202
Curtis Mathes 1504 3003
Daewoo 1298 3150
Emerson 1382 3213
1383 3202
GE 1164 3090
1380 3201
1381 3203
JVC 1299 3151
Magnavox 1302 3154
1321 3181
1300 3152
1301 3153
Magnin 1380 3201
MGA 1380 3201
Mitsubishi 1381 3203
Orion 1382 3213
1383 3202
Panasonic 1305 3158
1306 3159
Penney 1380 3201
Philips 1307 3160
1308 3152
Quasar 1165 3091
1166 3092
RCA 1167 3093
1168 3094
1310 3162
1380 3201
1381 3203
Samsung 1161 3089
Sansui 1382 3213
1383 3202
Sanyo 1380 3201
Sharp 1311 3163
1312 3164
Sylvania 1145 3095
Toshiba 1006 3096
1267 3168
1313 3165
1315 3167
1319 3182
1006 3166
Zenith 1118 3097
1382 3213
1383 3202

TV DVD VCR COMBO

DiamondVision 1499, 2280, 3038
Magnavox 1339, 2241, 3183
Panasonic 1123, 2075, 3087, 1152, 2076, 3086
RCA 1151, 2077, 3106
Samsung 1297, 2214, 3148
Sharp 1153, 2086, 3100
1378, 2292, 3200
Superscan 1498, 2288, 3039
Sylvania 1027, 2064, 3105, 1124, 2078, 3088
1296, 2213, 3147
Toshiba 1154, 2093, 3099, 1158, 2094, 3098
1338, 2094, 3149

TV VCR TUNER COMBO

TV Code VCR Code TUNER Code
Panasonic 1303 3155 5109
1304 3157 5111
1303 3156 5110
Philips 1309 3161 5112

TV VCR DVD TUNER COMBO

TV Code DVD Code VCR Code TUNER Code
Panasonic 1292 2211 3145 5107
1295 2212 3146 5108

TV RECEIVER

RECEIVER TV
GPX 5177 1320
Panasonic 5164 1010
Philips 5138 1390
Polaroid 5141 1393

DVD

Accele Vision 2429
Accurian 2421
Advent 2413
Aiwa 2026, 2131
Akai 2378
Alco 2010
Allegro 2039
Amphion MediaWorks 2342
AMW 2342
Apex 2001, 2056, 2057, 2061, 2095, 2098, 2229, 2250, 2262, 2316,
2322, 2330
Apex Digital 2261, 2266, 2291
Apple 2383
Arrgo 2325
Aspire 2415
Astar 2354
Audiovox 2010, 2132, 2373, 2388
Axion 2379
Bang & Olufsen 2324, 2370
Blaupunkt 2136, 2322
Blue Parade 2021
BOSE 2215, 2276
BOSE 2122, 2130, 2215, 2276
BOSS 2336
Boston 2034
Broksonic 2053, 2072, 2284
CambridgeSoundWorks 2395
Cinevision 2039, 2152, 2195
Clarion 2100,
Classic 2101, 2391
Coby 2380, 2387, 2414, 2423
Curtis 2387
Curtis Mathes 2420
CyberHome 2083, 2325
Cytron 2374
Daewoo 2039, 2058, 2062, 2137, 2138, 2190
Denon 2110, 2133, 2040, 2216, 2247, 2253, 2317
Desay 2344
DiamondVision 2280, 2382
Disney 2321, 2424
Durabrand 2326
DVD2000 2019
Eclipse 2335
Emerson 2002, 2059, 2073, 2321, 2327, 2392, 2418
Enterprise 2418
ESA 2327, 2394
Fisher 2112, 2134, 2255
Funai 2002, 2321, 2327
Gateway 2346
GE 2079, 2118, 2041, 2261, 2319, 2322
GFM 2263

Go Video 2039, 2046, 2124, 2127, 2129, 2230, 2239, 2249, 2346
GPX 2114, 2390
Gradiente 2430
Greenhill 2322
Grundig 2320
Harman Kardon 2125
Hitachi 2000, 2027, 2126, 2173, 2240
Hiteker 2262
iLive 2267
Ilo 2375
Initial 2322, 2381
Insignia 2222, 2327, 2369, 2394
Integra 2021, 2410
Irradio 2150
iSymphony 2259
Jensen 2414
JVC 2017, 2028, 2047, 2090, 2096, 2097, 2115, 2166, 2204, 2206,
2217, 2218, 2232, 2242, 2283, 2359, 2360, 2361, 2362, 2364, 2365,
2366, 2367
Kawasaki 2010
Kenwood 2142, 2148
KLH 2010, 2322
Konka 2030, 2376
Koss 2060, 2200, 2264, 2411, 2417
Landel 2422
Lasonic 2081
Lenoxx 2326, 2416
LG 2039, 2270, 2297, 2303, 2339, 2352, 2363, 2368, 2371, 2418
Liquid Video 2417
Liteon 2346, 2353, 2421
Magnavox 2002, 2018, 2089, 2237 2241, 2245, 2293, 2318, 2320,
2321, 2327
Marantz 2143, 2320
Memorex 2003, 2424
Microsoft 2319
Mintek 2004, 2322, 2381, 2419
Mitsubishi 2019, 2123, 2145, 2147
NAD 2059, 2139
Nakamichi 2116,
Nesa 2322,
Next Base 2422,
Nexxtech 2140, 2256, 2328
Norcent 2005, 2117
Onkyo 2006, 2219, 2220, 2318, 2410
Oppo, 2323, 2431, 2432
Oritron 2009, 2411, 2417
Panasonic 2031, 2066, 2075, 2076, 2104, 2105, 2106, 2111, 2151,
2153, 2154, 2155, 2167, 2179, 2188, 2198, 2207, 2211, 2212, 2221,
2228, 2248, 2258, 2268, 2272, 2275, 2277, 2300, 2318, 2384, 2385,
2386, 2398, 2399, 2425, 2426, 2427, 2428
Philips 2018, 2032, 2033, 2045, 2051, 2091, 2109, 2156, 2157, 2158,
2159, 2169, 2208, 2209, 2243, 2282, 2285, 2302, 2304, 2318, 2320,
2321, 2404
Pioneer 2008, 2021, 2160, 2164, 2191, 2223, 2224, 2310, 2337,
2400
Polaroid 2007, 2265, 2377, 2409
Polk Audio 2320
Presidian 2321
Proceed 2262
Proscan 2118, 2144, 2205, 2319
Protron 2149
Qwestar 2009, 2411
RCA 2010, 2021, 2048, 2055, 2063, 2077, 2099, 2107, 2118, 2161,
2165, 2172, 2177, 2181, 2261, 2281, 2287, 2289, 2319, 2322, 2331
Regent 2416
Rio 2039
Rotel 2028
Rowa 2412
Sampo 2119
Samsung 2012, 2029, 2049, 2074, 2085, 2102, 2120, 2175, 2186,
2196, 2214, 2233, 2246, 2271, 2274, 2279, 2286, 2290, 2294, 2295,
2299, 2311, 2314, 2333, 2340, 2347, 2351
Sansui 2071
Sanyo 2050, 2393
Sensory Science 2346
Sharp 2013, 2015, 2044, 2082, 2086, 2170, 2174, 2227, 2292, 2321,
2396
Sherwood 2121, 2397
Shinsonic 2273, 2419
Sonic Blue 2039

Sony 2014, 2020, 2022, 2065, 2067, 2068, 2069, 2070, 2087, 2103, 2108, 2113, 2162, 2171, 2176, 2178, 2182, 2187, 2189, 2192, 2193, 2201, 2202, 2203, 2226, 2238, 2244, 2251, 2257, 2273, 2278, 2296, 2298, 2305, 2306, 2307, 2309, 2313, 2315, 2329, 2332, 2338, 2355, 2356, 2357, 2405, 2406, 2407
Spectroniq 2149
Sungale 2343
Superscan 2288
Sylvania 2002, 2064, 2078, 2092, 2194, 2213, 2260, 2321, 2327, 2408
Symphonic 2321
Teac 2010
Techwood 2141
Theta Digital 2021
Toshiba 2023, 2025, 2037, 2038, 2040, 2041, 2054, 2080, 2084, 2088, 2093, 2094, 2168, 2180, 2183, 2184, 2185, 2197, 2210, 2231, 2235, 2284, 2301, 2318, 2334, 2341
Toshiba 2135, 2312, 2348, 2349, 2350, 2358, 2401, 2402, 2403, Trutech 2345, 2433
Urban Concepts 2318
US Logic 2419
Venturer 2010, 2011
Westinghouse 2372
Xbox 2319
Yamaha 2106, 2146, 2163, 2269, 2320, 2389
Zenith 2039, 2052, 2128, 2199, 2234, 2236, 2252, 2308, 2318, 2418

2233 3184
2290 3214
2311 3218
2311 3232
Sanyo 2050 3070
Sharp 2170 3176
2174 3177
Sony 2065 3104
2067 3085
2171 3179
2238 3187
2244 3192
2067 3178
2355 3224
2356 3225
2357 3226
2244 3240
Toshiba 2080 3103
2084 3102
2168 3180
2235 3185
2312 3219
2358 3227
2080 3241
Zenith 2052 3072
2128 3119
2234 3186
2236 3186

DVD TUNER COMBO

DVD Code TUNER Code
iSymphony 2259 5178

DVD VCR COMBO

DVD Code VCR Code
Apex 2229 3189
Broksonic 2072 3082
CineVision 2230 3242
Daewoo 2062 3076
Emerson 2073 3083
Go Video 2046 3066
2127 3110
2129 3109
2230 3188
2239 3193
2129 3221
Hitachi 2126 3117
2173 3169
Insignia 2369 3239
JVC 2047 3067
2097 3118
2166 3170
2232 3194
2166 3171
2359 3228
2360 3229
2361 3230
2362 3231
2364 3234
2365 3235
2366 3236
2367 3237
LG 2363 3233
2368 3238
Magnavox 2237 3190
Panasonic 2066 3078
2167 3172
2228 3191
Philips 2051 3071
2169 3173
Polaroid 2007 3111
RCA 2048 3068
2165 3174
2172 3175
Samsung 2049 3069
2074 3084
2085 3101

VCR

ABS 3223
Admiral 3001
Adventura 3021
Aiwa 3021
Akai 3055, 3058
Alienware 3223
American High 3016
Apex 3189
Audio Dynamics 3005, 3006
Bang & Olufsen 3222
Bell & Howell 3007
Broksonic 3081, 3082, 3202, 3213
Candle 3011, 3013, 3014
Canon 3016
Carver 3036
CineVision 3242
Citizen 3011, 3013, 3014
Colortyme 3005
Curtis Mathes 3000, 3003, 3005, 3014, 3016, 3212
CyberPower 3223
Cyberpower 3223
Daewoo 3011, 3013, 3021, 3076, 3120, 3150
DBX 3005, 3006
Dell 3223
DiamondVision 3038
Dimensia 3000
Dynatech 3021
Electrohome 3023
Emerson 3011, 3016, 3021, 3023, 3083, 3202
Fisher 3007, 3030
Fuji 3016, 3058
Funai 3002, 3021
Garrard 3021
Gateway 3223
GE 3000, 3016, 3090, 3201, 3203, 3212
Go Video 3066, 3073, 3109, 3110, 3188, 3193, 3221
Goldstar 3005, 3014
Gradiente 3021
Harley Davidson 3021
Harman Kardon 3005
Headquarter 3007
Hewlett Packard 3223
Hitachi 3052, 3055, 3117, 3169
Howard Computers 3223
HP 3223
Hush 3223
iBUYPOWER 3223
Insignia 3239

Instant Replay 3016
JC Penney 3005, 3006, 3007, 3016, 3030, 3036, 3052
JCL 3016
Jensen 3055
JVC 3005, 3006, 3007, 3014, 3055, 3060, 3067, 3118, 3121, 3122, 3123, 3124, 3125, 3126, 3127, 3151, 3170, 3171, 3194, 3205, 3228, 3229, 3230, 3231, 3234, 3235, 3236, 3237,
Kenwood 3005, 3006, 3007, 3014, 3055, 3060
Kodak 3016
LG 3233, 3238
Linksys 3223
Lloyd's 3021
Maganvox 3154, 3181
Magnavox 3016, 3036, 3051, 3061, 3128, 3152, 3153, 3183, 3190, 3206, 3211
Magnin 3201
Marantz 3005, 3006, 3007, 3014, 3016, 3036
Matsushita 3016
Media Center PC 3223
MEI 3016
Memorex 3001, 3004, 3007, 3016, 3021, 3051
MGA 3023, 3201
Microsoft 3223
Mind 3223
Minolta 3052
Mitsubishi 3023, 3060, 3108, 3203
Montgomery Ward 3001
Motorola 3001, 3016
Multitech 3021
NEC 3005, 3006, 3007, 3014, 3055, 3060
Niveus Media 3223
Northgate 3223
Olympus 3016
Optimus 3001
Optonica 3047
Orion 3004, 3202, 3213
Panasonic 3016, 3029, 3037, 3053, 3063, 3077, 3078, 3079, 3086, 3087, 3107, 3129, 3130, 3131, 3132, 3133, 3134, 3145, 3146, 3155, 3156, 3157, 3158, 3159, 3172, 3191, 3197, 3207, 3212
Penney 3201, 3212
Pentax 3052
Pentex Research 3014
Philco 3016, 3036,
Philips 3016, 3036, 3047, 3061, 3071, 3135, 3160, 3173, 3208, 3216
Philips Magnavox 3135
Pioneer 3006, 3060
Polaroid 3111
Portland 3013
Proscan 3000
Pulsar 3051
Quarter 3007
Quartz 3007
Quasar 3016, 3091, 3092, 3212
Radio Shack 3001, 3047
Radio Shack/Realistic 3007, 3016, 3021, 3023, 3047
RCA 3000, 3016, 3052, 3068, 3075, 3093, 3094, 3106, 3136, 3174, 3175, 3201, 3203, 3206, 3212
Realistic 3001, 3007, 3011, 3016, 3021, 3023, 3047
Ricavision 3223
Ricoh 3064
Runco 3051
Samsung 3011, 3069, 3084, 3089, 3101, 3148, 3184, 3214, 3215, 3218, 3232
Sanky 3001, 3051
Sansui 3004, 3006, 3055, 3060, 3202, 3211, 3213
Sanyo 3007, 3070, 3201
Scott 3011
Sears 3007, 3016, 3030, 3052, 3211
Sharp 3001, 3013, 3023, 3047, 3080, 3100, 3137, 3163, 3164, 3176, 3177, 3200,
Shintom 3058
Signature 3001
Singer 3016, 3064
Sony 3049, 3058, 3085, 3104, 3138, 3139, 3140, 3178, 3179, 3187, 3192, 3209, 3211, 3217, 3223, 3224, 3225, 3226, 3240
Stack 3223
Stack 9 3223
STS 3016, 3052
Superscan 3039
Sylvania 3016, 3021, 3036, 3061, 3088, 3095, 3105, 3147

Symphonic 3002, 3021
Systemax 3223
Tagar Systems 3223
Tandy 3007
Tatung 3055
Teac 3021, 3055
Technics 3016, 3053
Teknika 3016, 3021, 3050
Thomas 3211
Toshiba 3011, 3030, 3096, 3098, 3099, 3102, 3103, 3141, 3142, 3149, 3165, 3166, 3167, 3168, 3180, 3182, 3185, 3210, 3219, 3220, 3223, 3227, 3241
Touch 3223
Vector Research 3005, 3006, 3011
Victor 3006
Video Concepts 3005, 3006, 3011
Viewsonic 3223
Voodoo 3223
Wards 3001, 3011, 3016, 3021, 3023, 3047, 3052
White Westinghouse 3002
XR-1000 3016, 3021
Yamaha 3005, 3006, 3007, 3014, 3055
Zenith 3051, 3058, 3064, 3072, 3097, 3119, 3143, 3144, 3186, 3198, 3202, 3204, 3211, 3213
ZT Group 3223

HTIB

Audio Code DVD Code
Apex 4049 2316
Audiovox 4053 2388
BOSE 4000 2130
4000 2276
4000 2215
Boston 4067 2034
CambridgeSoundWorks 4060 2395
Classic 4055 2391
Coby 4052 2387
Curtis 4056 2387
Denon 4012 2216
Emerson 4057 2392
GPX 4055 2390
Insignia 4059 2394
iLive 4019 2267
JBL 4001 2043
JVC 4002 2035
4013 2217
4014 2218
4028 2283
Koss 4003 2060
4015 2200
LG 4041 2303
4025 2270
Magnavox 4035 2293
Onkyo 4004 2024
4016 2219
4017 2220
Panasonic 4005 2104
4018 2221
4030
4038 2300
4050 2384
4051 2385
4063 2275
4050 2272
4050 2277
4050 2386
Philips 4006 2036
4027 2282
4039
4042 2304
Pioneer 4007 2016
4020 2223
4021 2224
4029
RCA 4008 2042
4026 2281
4008 2161
Samsung 4033 2294

4036 2299
4033 2295
4065 2271
4047 2314
4064 2274
Sanyo 4058 2393
Sharp 4061 2396
4066 2227
Sherwood 4062 2397
Sony 4009 2113
4010 2108
4022
4023 2225
4024 2226
4031 2022
4034 2296
4043 2305
4044 2306
4045 2307
4046 2309
4048 2315
Sylvania 4068 2002
Toshiba 4040 2301
Venturer 4011 2011
Yamaha 4054 2389
4032 2269
Zenith 4037 2308

REC TUN

ADC 5144
Adcom 5174
Aiwa 5000, 5001, 5005, 5006, 5034, 5143
Akai 5083
Alco 5024
Amphion Media Works 5158
AMW 5158
Anam 5156
Audiotronic 5145
Audiovox 5024, 5152
B & K 5175
Bang & Olufsen 5151
BOSE 5007
Capetronic 5144
Carver 5000, 5143, 5145
Denon 5008, 5035, 5036, 5037, 5038, 5039, 5040, 5041, 5042, 5043, 5044, 5045, 5046, 5047, 5048, 5049, 5050, 5051, 5052, 5053, 5054, 5114, 5124, 5168
Eclipse 5149
Fisher 5159
GPX 5177
Gradiente 5153
Harman/Kardon 5000, 5009, 5055, 5056, 5142, 5143
Hitachi 5159
Integra 5155
iSymphony 5178
JBL 5009
JVC 5010, 5057, 5058, 5059, 5116,
Kenwood 5011, 5012, 5013, 5060, 5061, 5062, 5063, 5064, 5065, 5066, 5067, 5068, 5123, 5127, 5128, 5132, 5148
KLH 5024
Koss 5157
Linn 5000, 5143
Magnavox 5000, 5143, 5144, 5145
Marantz 5000, 5069, 5143, 5145
Mitsubishi 5070, 5071, 5072
NAD 5161
Niles 5004
Onkyo 5002, 5018, 5073, 5074, 5075, 5076, 5077, 5078, 5079, 5080, 5081, 5082, 5084, 5085, 5086, 5087, 5130, 5131, 5140
Optimus 5144, 5156
Oritron 5157
Panasonic 5019, 5020, 5107, 5108, 5109, 5110, 5111, 5115, 5126, 5164
Philips 5000, 5112, 5138, 5143, 5145, 5154
Pioneer 5021, 5022, 5088, 5089, 5090, 5091, 5092, 5093, 5094, 5119, 5120, 5144, 5147
Polaroid 5141
Polk Audio 5143, 5176

RCA 5024, 5025, 5026, 5137, 5144, 5156
Rio 5160
Rotel 5150
Samsung 5139
Sansui 5000, 5143
Sanyo 5159
Sherwood 5027
Sonic Blue 5160
Sony 5017, 5023, 5028, 5029, 5030, 5031, 5032, 5033, 5095, 5096, 5097, 5113, 5117, 5121, 5125, 5129, 5133, 5134, 5136, 5146, 5162, 5163, 5169, 5170, 5171, 5172
Sunfire 5011
Teac 5024, 5156
Technics 5016, 5019, 5020, 5098, 5099, 5100, 5101, 5115, 5122, 5126, 5173
Thorens 5145
Venturer 5024
Wards 5000, 5143
Yamaha 5003, 5014, 5015, 5102, 5103, 5104, 5105, 5106, 5118, 5135, 5155, 5165, 5166, 5167

AMPLIFIER

Adcom 6055
Aiwa 6003, 6020
BOSE 6060
Carver 6002
Citizen 6026
Curtis Mathes 6046
Denon 6014, 6039, 6057
Fisher 6002
GE 6028, 6045
Goldstar 6016
Harman/Kardon 6047
Hitachi 6034
JBL 6050
JVC 6018, 6024, 6041
Kenwood 6015, 6022
Krell 6013
Left Coast 6047
Magnavox 6035
Marantz 6000, 6047, 6058
McIntosh 6031
Nakamichi 6012
NEC 6033, 6048
Onkyo 6005, 6006, 6017, 6054, 6056
Optimus 6008, 6046
Panasonic 6001, 6040
Parasound 6059
Philips 6047
Pioneer 6004, 6009, 6010, 6023, 6036, 6046, 6051
Polk Audio 6047
Proton 6035
Quasar 6001
RCA 6025, 6046
Sharp 6029, 6030, 6032
Sherwood 6011
Shure 6048
Sony 6020, 6042, 6044, 6049
Soundesign 6045
Soundmatters 6021
Teac 6019
Technic 6001
Technics 6001, 6040
Toshiba 6027
Victor 6018, 6024
Wards 6004, 6045
Yamaha 6007, 6037, 6038, 6043, 6052, 6053