## **Quick Start Guide**

Use your phone for more than just talking

- CV
- Music Player
- 2.0 Megapixel Camera with Video Record
- Video Share

See User Manual for Spanish Instructions

Additional charges may apply. Visit att.com for more details. Phone features subject to change without prior notice. All phone screens are simulated. Select services are only available on an AT&T nation rate plan and may not be available in all markets.

Shine





# Getting to Know Your Phone





#### AT&T Mobile Music

AT&T Mobile Music provides the ultimate music experience. Listen to your favorite music, watch the latest music videos, and stay in the know with music news and more.

- From standby mode, press the Left Soft Key for Menu, select AT&T Music (6), and pick from:
  - Transfer and listen to your music with the integrated **Music Player**
- Stream dozens of commercial-free music stations with **XM Radio**
- Watch the latest music videos by clicking on **Music Videos**
- Personalize with ringtones and Answer Tones™ under **Shop Music**
- Instantly ID the title and artist of a song with **MusicID**
- Get the latest music news, charts, and concert info from **The Buzz**






\*\*Steps may vary depending on Windows Media Player version. **Warning!** Do not disconnect phone while file transfer is in progress.

### **Transfer Music**

- Make sure your music is in MP3, WMA, AAC, AAC+, or eAAC+ format.
- 2. Insert the microSD™ card\* (gold contacts facing down) into the slot on the left side of the phone.
- Power on the phone and connect it to your PC using a USB data cable.\*
- Once the Portable Device screen pops up, select the second option and click OK.
- From within Windows Media Player, songs will populate the left side of the screen. CU720 Music Sync Player should be the destination for the songs on the right side of the screen.
- Check/drag\*\* songs to be transferred, then click the **Start Sync** button to sync them to the Shine.
- When finished, unlock the keypad, press the Right Soft Key, then Yes (1), and disconnect the USB cable.

**Requirement:** Windows Media® Player 10 or higher. Not compatible with Mac OS or iTunes.





# Play Music

Listen to music from your favorite artists right on your phone. To listen to music that you have transferred to your phone, follow these quick and easy steps:

- From standby mode, press the Left Soft Key for Menu, select AT&T Music (6), then Music Player (1).
- 2. Select All Songs (1), Playlists (2), Artists (3), Albums (4), or Genres (5).
- Press to play/pause. Push up or down on the Navigation Joystick to adjust the volume, and left or right to go to the previous or next song.
- Press the Left Soft Key for Minimize to access other phone functionality while music is playing.





#### CV

CV brings your phone to life. Watch news, sports, weather, and entertainment clips on the go.

- From standby mode, press the Left Soft Key for Menu and select CV (1).
- 2. Once connected, select the program or category you wish to view and press .

#### Personalize your CV Home Page

- 1. From the CV home page, select **EDIT** and press .
- Select the content you would like added or deleted from your CV home page and press .

**Note:** Parental Controls available. See box insert for details. Access to CV requires a MEdia<sup>™</sup> Max plan.





\*1600 x 1200 and 1280 x 960 resolutions do not support zoom.

# Take Pictures/Record Video

Capture everything around you in vivid detail via the 2.0 megapixel camera with video and share it instantly.

#### Taking a Picture

- 1. Press the **(C) Key**. Rotate phone horizontally.
- Push up or down on the Navigation Joystick to adjust brightness and left or right for zoom.\* Press the Right Soft Key for other options.
- 3. Press to take the picture. Press the **Left Soft Key** to send.

#### Recording a Video

- 1. Press and *hold* the **O Key**.
- 2. Select Record Video (2). Rotate phone horizontally.
- 3. Press ( ) to start and stop recording.

**Note:** Push **left** on the **Navigation Joystick** in standby mode to see your pictures/videos.





### Video Share

Share events the moment they happen. Video Share lets you stream live video directly to friends and family.

- Dial the 10-digit phone number of another 3G Video Share capable phone.\*
- A few seconds after initial connection, Video Share Ready will display at the top of both screens. At this point, either calling party may start one-way video sharing.
- 3. Press the **Key** to share. It will take a few seconds to establish a video share connection.
- 4. To end video sharing, select the  $\Box$  icon, then **Yes (1)**.

\*Video Share is not available in all markets. Both parties must be in a 3G service area—a **3G** icon must appear by the signal bars prior to a call being placed, and both parties must remain in the 3G coverage area for the duration of the video share session.



Trademarks are property of their respective owners.

## Mobile Email

Take your email with you. With Mobile Email, you can quickly and easily access your email if your account is with one of these providers: Yahoo!®, AOL®/AIM, Windows Live™ Mail or AT&T® Yahoo!

- From standby mode, press the Left Soft Key for Menu, select Messaging (2), then Mobile Email (4).
- 2. Select a provider and press 🔘.
- Enter your Screen Name/ID or Email and Password. Then press the Left Soft Key to Sign In/On.
- 4. Scroll to the email message you want to access and press to download its content.
- 5. Press the **Left Soft Key** to delete, reply, or forward.



All providers may not be available on all devices. Yahool and the Yahool logo are trademarks and/or registered trademarks of Yahool Inc. ADL, America Online and the Triangle Logo are registered trademarks of America Online. Windows Live and the Windows logo are either registered trademarks or fall Wirnsoft Comparation in the United States and/or other countries.



# **Text Messaging**

When you need to communicate privately and quickly, use text messaging. You can text message to other wireless phones and email addresses

- From standby mode, push up on the Navigation Joystick.
- 2. Type your message.
- 3. When completed, press
- Enter the recipient's phone number or select a contact and press .
- 5. Press the **Left Soft Key** to send.





Trademarks are property of their respective owners.

# Instant Messaging

If you subscribe to an IM service such as AIM®, Windows Live<sup>™</sup>, or Yahoo!<sup>®</sup>, you can take the fun of IM on the go with your wireless phone.

- 1. From standby mode, push right on the **Navigation Joystick.**
- 2. Select an IM community, then select Sign In/On (1) and press .
- 3. Enter your Screen Name/ID or Email and your Password. Check the Auto Sign On/In box to be automatically connected in the future. Press the **Left Soft Key** to **Sign In/On**.
- 4. Select a contact currently online and press .



5. Enter your message and press ( ) to send. To end, select Option, then End Conversation.

Note: When you receive an incoming instant message, a "new message" icon similar to this one (=) will appear on the screen.





### MEdia™ Net

With MEdia™ Net, you can get the information that is important to you at a glance. Your local weather, your teams' scores, and your movie theaters are all just a few clicks away.

- 1. From standby mode, press and **hold** to launch MEdia Net
- 2. Scroll and highlight the content you want to view and press .

#### Personalize your MEdia Net Home Page

- From the MEdia Net home page, select EDIT (next to My Links) and press .
- Select the content you would like added or deleted from the MEdia Net home page and press .





# Multitasking

Multitask simultaneously with voice and data — browse the web, make calls, play games, send and receive messages, and listen to music. All at once.

- If you're involved in one task and want to launch another, press the Key (on the right side of the phone), then press the Left Soft Key for Menu, select the task you want to launch, and press .
- To switch among multiple open tasks, just press the Key to display the task icon bar on the bottom of the screen, push left or right on the Navigation Joystick to select another task icon, and press .
- If you get a call while in another task (except playing music), you can accept the call, then return to the task while you're talking.



28 29


30 31

Options

# Organize Me

Stay organized and on schedule with time saving tools including a calendar, alarm clock, and notepad. All of these great tools are just a few clicks away.

- From standby mode, push left on the Navigation Joystick.
- 2. Select **Tools (6)** and press .
- Select Voice Command (1), Alarm Clock (2), Calendar (3), Notepad (4), or one of the other handy tools.



### Downloadable Fun

Personalize your phone with downloadable games, graphics, and ringtones. AT&T gives you access to the latest games and graphics right on your phone and access to the best new ringtones from today's hottest artists. Personalize your phone today.

- From standby mode, press the Left Soft Key for Menu.
- 2. Select AT&T Mall (5) and press O.
- 3. Select Shop Ringtones (1), Shop Games (2), Shop Graphics (3), Shop Multimedia (4), Shop Applications (5), or Shop Videos (6) and press .
- 4. Choose a category and press .

# **Optional Accessories**

Accessories for productivity, convenience, and fashion are available at att.com/wireless.



Stereo Headset\*



USB Data Cable\*



MicroSD™ Card



Carrying Case



Vehicle Power Charger



Bluetooth® Headset\*