



Wireless Tips For Seniors (And Everyone Else)

- **Voice mail.** Press and hold the "1" button to set-up and call your voicemail (works on most carriers and models).
- **Calling.** To make a call, dial the number and then press the green "send" button to initiate the call.
- **Home screen.** Press the red "end" button to return to your home screen from any menu screen. This also will end or "hang up" a call.
- **ICE.** Program the name "ICE" into your address book with your emergency contact's numbers. ICE stands for In Case of Emergency. If you need help, first responders will know who to call by looking for your ICE contact.
- **Charging.** Plug the device into the wall to charge; device will read "fully charged" when it's done. It will not damage the phone to leave it charging past this point, you can also use the phone before it's finished charging. For the best battery life, don't leave the phone in a place with extreme hot or cold temperatures.
- **Emergency phone.** If the phone is used just in the case of an emergency, it's a good idea to keep a car charger in your vehicle. In case the phone battery has died since you last charged it, you'll be able to plug the phone in and use it.
- **Battery and signal strength.** The amount of battery left appears on your home screen in the outline of a battery. The battery is "full" when the icon is completely shaded in. The signal strength is also on the home screen and is represented by stair-stepping bars. The more bars, the better the signal.
- **Address book.** Type names into the address book of a standard phone by pressing the key with the appropriate letter on it, the number of times as the letter's position on the key. For example, for "b" you press the "2" key twice. For "s" you press the "7" key four times.