

USER GUIDE

LG Watch Urbane™

2ND EDITION | *LTE*
LG-W200A

Thank you for choosing LG. Please carefully read this user guide before using the device for the first time to ensure safe and proper use. Visit the LG website at www.lg.com to obtain the latest version of this manual.

- Always use genuine LG accessories. The items supplied are designed only for this device and may not be compatible with other devices.
- Due to the touchscreen, this device is not suitable for the visually impaired.
- Descriptions are based on the device's default settings.
- Default apps on the device are subject to updates. Support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Center. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or loss. Such actions will violate your LG license agreement and void your warranty.
- Some content and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
- The apps on your device, and their functions, may vary according to country, region or hardware specifications. LG will not be responsible for any performance issues which arise from using applications developed by providers other than LG.
- LG will not be responsible for performance or incompatibility issues which arise from edited registry settings or modified operating system software.
- Any attempt to customize your operating system may lead to the device or its apps not working correctly.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are entirely responsible for the illegal use of media.
- Additional charges may apply for data services, such as messaging, uploading, downloading, auto-syncing and location services. To avoid additional charges, select a data plan suitable to your needs. Contact your service provider for details.

Instructional Notices



WARNING

Situations that could cause injury to yourself and others, or damage to the device or other property.



NOTE

Notices or additional information.

Table of Contents

Safety Information.....	5	Call Notifications	38
Basic.....	16	Change When Notifications Arrive.....	39
Accessories	17	See Remaining Battery or Date	39
Watch Layout	18	Access the Sound Settings.....	40
Charging the Watch	20	Turn Your Screen Off Temporarily with Theater Mode.....	40
If the Screen Freezes	22	Boost Screen Brightness Temporarily	41
Installing the SIM Card	23	Access the Settings Menu.....	41
Turning the Watch On and Off.....	26	Manage Storage.....	41
Connecting to Another Mobile Device	27	Tasks Using Voice Command	42
Touch Screen Tips.....	27	Change the Apps You Use for Voice Actions	44
Wearing the Watch	28	Take or View a Note.....	45
Heart Rate Sensor	29	Set a Reminder.....	46
Connecting the Watch to a Mobile	31	Show Me My Steps	46
Device.....	31	Show Me My Heart Rate	47
Before Pairing	32	Send a Text	48
How to Pair Your Watch	33	Email.....	49
After Pairing.....	33	Agenda	50
How to Use Your Watch	34	Navigate.....	50
Start on Your Watch Face (Where You See the Time)	35	Set a Timer	51
Quickly Dim the Screen.....	35	Use the Stopwatch	51
Changing the Watch Face.....	35	Set an Alarm.....	52
Notification Cards.....	36	Show Alarms	52
Block Notifications	37	Using Apps	53

Downloading Other Apps.....	54	More Information.....	67
Phone.....	54	Open Source Software Notice Information	68
Call Forwarding	56	Trademarks.....	68
Messenger.....	58		
LG Health	59		
Use the Google Fit App.....	60		
Settings.....	61		
Launching the Settings Menu.....	62		
Adjusting Display Brightness	62		
Change Your Watch Face	62		
Change the Font Size	62		
Gestures.....	63		
Screen On/Off Settings.....	63		
Sound.....	63		
Wi-Fi.....	63		
Bluetooth Devices.....	64		
Cellular	64		
Location.....	64		
Airplane Mode.....	65		
Accessibility	65		
Date & Time.....	65		
Screen Lock.....	65		
Permissions	65		
Unpair with Phone.....	66		
Power Off.....	66		
About.....	66		



Safety Information

Before turning on your product, review the basic safety information provided here.

General Safety & Handling

While using your product, be aware of the following common-sense guidelines.

Your environment

- **Safe operating temperatures.** Use and store your product in temperatures between 0°C/32°F and 40°C/104°F. Exposing your product to extremely low or high temperatures may result in damage, malfunction, or even explosion.
- **While driving.** When driving a car, driving is your first responsibility. Using a mobile device or accessory for a call or other app while driving may cause distraction. Keep your eyes on the road.
- **Around explosives.** Do not use in areas where sparks from the product might cause a fire or explosion.
- **On airplanes.** Observe all rules and instructions for the use of electronic devices. Most airlines allow the use of electronics only in mid-flight, not during take-off or landing. There are three main types of airport security devices: X-ray machines (used on items placed on conveyor belts), magnetic detectors (used on people walking through security checks), and magnetic wands (hand-held devices used on people or individual items). You can pass this product through airport X-ray machines. Do not send it through airport magnetic detectors or expose it to magnetic wands.
- Always follow any special regulations in the area you are located. Turn your device off in areas where use is forbidden, or when it may cause interference or danger.
- Changing the wrist straps to metallic might cause Bluetooth®/Wi-Fi connectivity issues.

Safety Tips

WARNING

- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
Wash hands after handling.
- The charging cable contains strong magnets that may interfere with pacemakers, credit cards, watches, and other magnet-sensitive objects.
- To avoid damaging your product and reduce the risk of fire or electric shock, explosion, or other hazards, observe these common-sense precautions:
 - Always use LG-approved cables, chargers, and other accessories. Using any other types may void any approval or warranty applying to the device and may be dangerous.
 - Available accessories may vary depending on your region, country or service provider.
 - Some content and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
 - Do not drop, strike, or shake your product.
 - Do not damage the power cord by bending, twisting, pulling, heating, or placing heavy items on it.
 - This product is equipped with a USB cable for connecting to a desktop or notebook computer or to the charger. Be sure your computer is properly grounded before connecting the product to the computer. The power supply cords of desktop or notebook computers have an equipment-grounding conductor and a grounding plug. This must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
 - Do not attempt to repair or modify or re-manufacture the product. It is equipped with an internal rechargeable battery which should be replaced only by LG or an authorized LG repair center.
 - Do not open, disassemble, crush, bend or deform, puncture, or shred the product.
 - Do not insert foreign objects into the product.

- Do not place the product in a microwave oven.
- Do not expose the product to fire, explosion, or other hazards.
- Clean with a soft, damp cloth. Do not use harsh chemicals (such as alcohol, benzene, or thinners) or detergents to clean your product.
- Dispose of your product and battery separately from household waste and in accordance with local regulations.
- Like many electronic devices, this product generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Use care when handling your product during or immediately after operation.
- If a problem arises using this product, stop using it and consult with an authorized LG Electronics customer service center.
- Do not immerse or expose the product to water or other liquids.

Heart Rate Precautions

- Pedometer, sleep, exercise, and heart rate are not intended to treat or diagnose any medical condition, and should be used for leisure, well-being and fitness purposes only.
- Heart rate readings can be affected by measurement conditions and your surroundings. Make sure you are seated and relaxed before reading your heart rate.
- This product is water and dust-resistant according to the IP67 Rating, which tests submersion in water at up to 1 meter for up to 30 minutes. It is not shockproof. The case must be completely closed.
- Heart rate readings may be affected by skin condition, measurement conditions and your surroundings.
- Never look directly at the light of the heart rate sensor, as this may damage your eyesight.
- If your device becomes hot, remove it until it cools down. Exposing skin to hot surfaces for a long period of time may cause burns.
- The heart rate feature is only intended for measuring your heart rate and must not be used for any other purposes.

Battery Warnings

- Do not disassemble, open, crush, bend or deform, puncture or shred the device.
- Do not modify or re-manufacture the device, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, or expose to fire, explosion or other hazard.
- Make sure that no sharp-edged items, such as animals' teeth or claws, come into contact with the battery. This could cause a fire.
- Only use the battery for the device for which it is specified.
- Only use the battery with a charging system that has been qualified with the device, per CTIA Certification Requirements for Battery System Compliance to IEEE1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard. Only authorized service providers can replace the battery (If the battery is not user-replaceable).
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and you suspect damage, take it to a service center for inspection.
- Improper battery use may result in fire, explosion or other hazards.
- Always unplug the charger from the wall socket after the product is fully charged to save unnecessary power consumption.
- There is risk of explosion if the battery is replaced with an incorrect type.
- To dispose of the battery properly, call (800) 822-8837 or visit www.call2recycle.org.

Embedded Battery

WARNING: Notice for battery replacement

- For your safety, do not remove the battery inside the product. If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- The Li-Ion Battery is a hazardous component which can cause injury.
- Battery replacement by non-qualified professionals can cause damage to your device.

Notes on Water-Resistant Properties

This product is water and dust-resistant in compliance with the Ingress Protection rating IP67*.

* This IP67 rating means that the product will maintain operability even if it is gently submerged in a tank of tap water at room temperature for about 30 minutes, up to a depth of 1 meter.

Avoid exposing the product to environments with excessive dust or moisture. Do not use the product in the following environments.



Do not immerse the product in any liquid chemicals (soap, etc.) other than water.



Do not immerse the product in salt water, including seawater.



Do not immerse the product in a hot spring.



Do not swim while wearing this product.



Do not use the product underwater.



Do not place the product directly on sand (such as at a beach) or mud.

- Drain the water if the voice activation does not work properly due to water in the microphone.
- Do not use the product in places where it may be sprayed with high-pressure water (e.g. near a faucet or shower head) or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.

- This product is not resistant to shock. Do not drop the product or subject it to shock. Doing so might damage or deform the main unit, causing water leakage.

Pacemakers and Other Medical Devices

Persons with pacemakers should:

- ALWAYS keep the product more than six (6) inches from their pacemaker when the product is turned ON.
- Not carry the product in a breast pocket.
- Use the wrist opposite the pacemaker to minimize the potential for RF interference.
- Turn the product OFF immediately if there is any indication that interference is taking place.

If you use any other personal medical device, consult your physician or the manufacturer of your medical device to determine if it is adequately shielded from external RF energy.

Tips for Using Bluetooth and Wi-Fi on Your Watch

- When connecting your product to other mobile devices, the devices must be positioned close to each other. Failure to do so may cause abnormal operation or noise, depending on the environment.
- In an open space, the Bluetooth communication range usually spans approximately 32 feet (10 m). This range may vary depending on the environment.
- Do not place obstacles between your product and connected devices. Outgoing/incoming signals may be weakened due to the user's body, walls, corners or obstacles. Make sure there are no obstacles during use.
- When using a Wi-Fi connection, your watch can get notifications from your device even if Bluetooth is unavailable.
- Your watch will search for and connect to the nearest Wi-Fi network based on the Wi-Fi list registered on your phone.

Tips for the Display Screen

- Do not display non-moving images for an extended period. This may cause image burn-in or stains on the screen.
- Applications that display the same screen for more than 10 minutes are not recommended, since the potential screen damage is not covered by warranty.

Exposure to Radio Frequency(RF) Energy

In August 1996, the U.S. Federal Communications Commission (FCC), with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to Radio Frequency (RF) electromagnetic energy emitted by FCC-regulated transmitters. The design of this product complies with the FCC guidelines and these international standards.

Next-to-Mouth and Wrist-Worn Operation

This device was tested for typical body-worn (wrist) operations with the back of the device kept 0 inches (0 cm) between the user's body (wrist) and the back of the device.

This device was also tested for typical next-to-mouth (face) operations with the front of the device kept 0.39 inches (1 cm) between the user's mouth (face) and the front of the device.

To comply with FCC/IC RF exposure requirements, a minimum separation distance of 0.39 inches (1 cm) must be maintained between the user's mouth (face) and the front of the device.

Any accessories containing metallic components may not be used.

Specific Absorption Rate (SAR) Values

This product transmits and receives radio signals. It is designed and manufactured not to exceed the emission limits for exposure to Radio Frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless products employs a unit of measurement known as the Specific Absorption Rate, or SAR. In the United States and Canada, the SAR limit for wrist watch used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue, or 4.0 watts/kg (W/kg) averaged over ten grams of tissue.

SAR tests are conducted using standard operating positions specified by the FCC, with the product transmitting at its highest certified power level in all tested frequency bands.

Although SAR is determined at the highest certified power level, the actual SAR level of the product during operation can be well below the maximum value.

Because the product is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output. The highest SAR value for this product is 0.51 W/kg (1 g) when tested for use at next-to-mouth (face) level and 2.88 W/kg (10 g) for bodyworn (wrist) use.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this product with all reported SAR levels evaluated, in compliance with FCC RF emission guidelines.

SAR information on this model product is on file with the FCC and can be found under the Display Grant section of

<http://transition.fcc.gov/oet/ea/fccid/> after searching on FCC ID ZNFW200A.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.ctia.org/>.

* Product meets current FCC Radio Frequency Exposure Guidelines
FCC ID : ZNFW200A

Part 15.19 Statement General Requirement

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Part 15.21 Statement

Changes or modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

U.S. Declarations of Conformity (Part 15.105 Statement)

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference or television reception, which can be determined by turning the equipment off and on, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Basic

Accessories


These accessories are available for use with your device.

- Travel adaptor
- Quick Start Guide
- Magnetic charging cable
- SIM Cap opener

NOTE

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- The items supplied with the device and any available accessories may vary depending on the region or service provider.

Watch Layout



NOTE

- The touch screen must not come into contact with any other electrical devices. Electrostatic discharge can result in the touch screen malfunctioning.

Power Key

To turn the watch on:

- Press and hold for one second to turn the screen on. If it doesn't turn on, press and hold for a few seconds until the LG logo appears.

If the screen freezes:

- Press and hold for over 10 seconds until the LG logo appears to restart the watch.

When the device is idle:

- Press once quickly to wake the screen.
- Press twice to turn the Theater mode on.
- Press three times to turn the Brightness boost mode on.
- Press and hold for a few seconds to access the app list.


**Top / Bottom
Key**

When the device is idle:

- Press the **Top Key** to launch Contacts.
- Press the **Bottom Key** to launch LG Health.

During a call:

- Control the volume.




⚠ WARNING

- Do not close or push the hole located at the bottom of the device with a sharp object. Doing so may cause your device to work improperly.
- Any damage to the barometer or microphone resulting from accidents, unreasonable use, tampering or other causes not arising from defects in material or workmanship may void the Limited Warranty.

⚠ WARNING: Before wearing the strap

- Excess force on the watch band may lead to breakage.



Charging the Watch

Before using your watch for the first time, you should charge the battery. Use the charging cable included with the watch to charge the device's battery.

You can also charge the device's battery using a computer. Simply connect the computer to the charging cable using the USB cable included with the watch.

NOTE

- When battery power is low, the battery icon is displayed as empty. If the battery charge is completely empty, the watch cannot be turned on immediately after connecting the charger. Leave an empty battery to charge for a few minutes before turning the device on. Some features are not available while the battery is charging.

WARNING: Corrosion of charging terminals

- Exposure to sweat or other foreign material during the use of the product may cause the charging terminals to corrode while charging. To prevent this, wipe the product with a cloth before charging.


- 1 Locate the charging terminals on both the watch and the charging cable.



NOTE

- The charging cable is designed to only be used with the watch and is not compatible with other devices.

- 2 Place the watch on the charging cable and make sure that the charging terminals are aligned with each other.




- 3 Connect the charging cable to a power outlet and place the watch on it. If your watch is turned off, it will turn on automatically.

 **NOTE**

- Make sure the watch is firmly connected to the charging cable before connecting the cable to a travel adapter or PC.

- 4 After the charging cord is connected to a power outlet, you will see a charging screen, shown as below, while charging. You can check the percent of remaining battery and the time. Swipe right to return to the watch face.



- 5 Once the watch battery is fully charged, disconnect the device from the charging cable.

- 6 The charging cable is equipped with a magnet inside. Do not leave metal objects nearby when separated from the watch. Contact with metal may lead to damage to the travel adapter or PC.

 **NOTE**

- The touch screen may not function if power to the watch is unstable while charging.
- The watch may become warm while charging. This is normal. If the battery becomes hotter than usual, disconnect the charger.

If the Screen Freezes


If the device freezes up and stops working, press and hold the **Power Key** for over 10 seconds until the device reboots and the LG logo is displayed.

Installing the SIM Card


NOTE

- Please power off the device before you insert or remove a SIM card.
- Don't use excessive force when you turn the SIM cap using the SIM cap opener.


- 1 Open the SIM cap using SIM cap opener as shown in the figure below. Align the SIM cap opener to the hole located at the bottom of the device and then turn counter-clockwise until the SIM cap direction indicator reaches the "UNLOCK" position.




- 2 To remove SIM cap, hold the watch firmly in one hand. Press the outer corner of the SIM cap after removing the SIM cap opener, the other side will lift. Then, lift off the SIM cap with your other hand as shown in the figure below.



- 3** Slide the Nano SIM card into the SIM card slot as shown in the figure. Make sure the gold contact area on the card is facing downward.




- 4** Close the SIM cap using the SIM cap opener as shown in the figure below. Align the SIM cap opener to the hole located at the bottom of the device and then turn clockwise until the SIM cap direction indicator reaches the "LOCK" position.



NOTE

- Foreign materials on the SIM cap sealing pad or SIM cap may compromise the water resistant function. Make sure to clean or remove any foreign material.



Unlock the SIM Card


If you insert the SIM card with a PIN lock, you have to enter the unlock code. If the SIM card PIN is disabled, ignore this section.

- 1 After turning the watch on, swipe up from the bottom of your watch screen until the SIM Locked screen appears.
- 2 Tap the SIM Locked screen to enter the unlock code.
- 3 Enter the unlock code.


Turning the Watch On and Off

Turning on the Watch

Turn the watch on by pressing and holding the **Power Key** (on the right-hand side of the device) for a few seconds. The screen lights up and the LG logo is displayed.



Turning off the Watch


- 1 Press and hold the **Power Key** until the app list appears.
- 2 Tap **Settings** > **Power off**.
- 3 When prompted with the message **Power off: Are you sure?**, tap .

Connecting to Another Mobile Device

If you want to connect your watch to another device, you must reset your device.

Reset Your Watch

This setting unpairs the watch from your phone, resets your watch's settings to their factory default values, and deletes all of your data.

- 1 Press and hold the **Power Key** until the app list appears.
- 2 Tap **Settings** > **Unpair with phone**. You are prompted to confirm.
- 3 Tap .
 - Your watch connects to one mobile device at a time.
 - Unpairing with your phone erases all data from your watch's memory. After completion, it is ready to connect to another mobile device.

Touch Screen Tips

Here are some tips on how to navigate on your watch.

- **Tap or touch** – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.
- **Touch and hold** – Touch and hold an item on the screen by tapping it and not lifting your finger until an action occurs.
- **Swipe or slide** – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first tap it.



Tap or touch



Touch and hold



Swipe or slide

Wearing the Watch

Cautions for Water-Resistance

Your watch has undergone testing in a controlled environment and is proven to be water and dust-resistant in certain circumstances (meets the requirements of classification IP67 as described by the international standard IEC 60529 - Degrees of Protection provided by Enclosures [IP Code]; test conditions: 15° C/59° F ~ 35° C/95° F, 86 - 106 kPa, 1 meter (approximately 3 feet), for 30 minutes). Despite this classification, your device is not fully resistant to water damage.


- The watch must not be immersed in water deeper than 3 feet (approximately 1 meter) and kept submerged for longer than 30 minutes.
- The device must not be exposed to **water at high pressure**, such as ocean waves or a waterfall.
- Should your watch or your hands become wet, dry them thoroughly before handling the device.
- The device must not be exposed to **salt water, ionized water or soapy water**.
- The watch's water and dust-resistant features may be damaged **by dropping or receiving an impact**.
- If the watch gets wet, use a clean, soft cloth to dry it thoroughly.
- The touch screen and other features may not work properly **if the device is used in water or any other liquid**.
- **If the watch has been immersed in water or if the microphone or speaker has gotten wet**, in-call sound quality may be affected. Wipe the microphone or speaker with a dry cloth to ensure it is clean and dry.

Caution on Product Overheating

Overheating the product to certain temperature will trigger a warning in order to prevent product breakage, skin irritation or damage, battery leakage, etc. Further rise in product temperature will turn off the power. Stop using the device if you feel discomfort due to overheating during use.

Heart Rate Sensor

Make sure your watch is positioned on your wrist correctly before measuring your heart rate.



NOTE

- Loose fitting or too much movement may cause inaccurate measurements.
- Never look directly at the heart rate sensor light as this may damage your eyesight.
- Escaping light may lead to inaccurate measurements. Wear the device so it doesn't touch your wrist bone when taking measurements.

Ensuring Accurate Measurements

Heart rate readings may be inaccurate depending on conditions and surroundings. Follow these steps for more accurate heart rate readings:




- Never measure your heart rate after smoking or drinking alcohol. Smoking and/or alcohol can affect your heart rate.
- Never take heart rate measurements at low temperatures. Keep yourself warm when you measure your heart rate.
- Users with thin wrists may find their heart rate measurements are inaccurate.
- When measuring your pulse for workout purposes, take the measurement while seated and relaxed before exercise, then proceed with your workout.
- If the measurement significantly differs from predicted values, relax and measure again in 30 minutes.
- Confirm your pulse by taking the average of around 5 repeated measurements.
- If you speak, yawn or breathe deeply during the measurement, you may see inaccurate values.
- Light reflection may be uneven depending on your circulation, blood pressure or skin condition, and may lead to inaccurate measurements.
- If light reflection is blocked by body hair or other items, you may obtain inaccurate measurements.
- If the heart rate sensor is dirty, wipe the sensor and try again for a more accurate measurement.

A decorative graphic consisting of several sets of horizontal lines in white and red, arranged in a descending staircase pattern from the top left towards the bottom right. The lines are grouped into sets of three or four lines each, with the color alternating between white and red for each set.

Connecting the Watch to a Mobile Device

Before Pairing

Before pairing, please do the following on the phone.

- 1 Make sure that the Android operation system on your phone is version 4.3 or higher and supports Bluetooth.
 - To find out whether your phone supports Android Wear, visit <http://g.co/WearCheck> from your phone.
 - If your phone is not Android 4.3 or later, please check with your manufacturer for a possible software update.
- 2 Make sure your phone is next to your watch.
- 3 On your phone, download the **Android Wear**  app from the **Play Store**  and install it. Check that the **Android Wear**  app is installed and updated to the latest version on your phone.
- 4 Make sure your phone is connected to mobile data or Wi-Fi. You will need a data connection to set up your watch for the first time.
- 5 Keep the watch connected to power during setup.


NOTE

- Your watch will turn on automatically while charging. Depending on the software installed, your watch may automatically download and install an update.
- Depending on the network connection, the setup process might take over 20 minutes.

How to Pair Your Watch

- 1 Turn on the watch and swipe the welcome screen left to begin.
- 2 Tap a language.
- 3 Connect your watch to a power source and swipe left to continue.

NOTE

- If the battery is at less than 20%, charge your watch first before proceeding the next step.
- 4 Swipe left following the on-screen instructions until the watch name is displayed.
 - 5 Open the **Android Wear**  app on your phone. Turn Bluetooth on during setup, if it isn't already on.
 - 6 On your phone, you'll see a list of nearby devices. Tap your watch's name.
 - 7 You'll see a pairing code on your watch and phone. Check that the codes match.
 - 8 Tap **Pair** on your phone to start pairing.
 - 9 You'll see a confirmation message on your watch once it is paired. This may take a few minutes.
 - 10 Follow the onscreen instructions to complete the initial setup.

After Pairing

To have the best Android Wear experience, we recommend turning on **Google Now** and **Location Services**. Go to **Google settings** or **Settings** on your phone if they aren't already on.



How to Use Your Watch

Start on Your Watch Face (Where You See the Time)

Start by waking up your watch. If your watch's screen is dimmed, you can wake up the watch by doing any of the following:

- Touch the screen.
- Turn your wrist so your watch face is upright.
- Press the **Power Key** on the watch.

Quickly Dim the Screen


- Press the **Power Key** on the watch.

OR


- Press your palm onto the screen until it vibrates. This will dim the watch face.

Changing the Watch Face

- 1 Touch and hold anywhere on the watch face for a few seconds.
- 2 Swipe the screen right or left to browse designs, then tap to choose one.




NOTE

- You can also change and download watch faces through the **Android Wear**  app.

Notification Cards


Most notifications you see on your phone will also show up on your watch. These include notifications for missed calls, texts, event reminders, and more.

Notifications are displayed in the form of cards at the bottom of the watch face.



Card previews

Swipe down on the card to hide it.



To View Cards

To view cards, swipe up from the bottom of your screen.

Tap a card to see more info. To see more cards, keep swiping up from the bottom of the screen.

To Remove a Card


To remove a card, swipe from left to right.


Once you're done looking at a card, you can get rid of it. If you remove a card on your watch, the same card or notification will be dismissed on your phone.

To See More Details

To see more details, swipe the card from right to left. Some cards provide more details or have actions you can take.

To Bring a Card Back




After the card has been dismissed, swipe down from the top of your watch's screen and tap the **Undo** button . You'll have a few seconds to get the card back. If you've swiped away the last card in your stream, you'll need to swipe up from the bottom of the screen to see the Undo button.






Block Notifications

If you get notifications on your phone that you don't want to see on your watch, you can stop specific apps from showing up on your watch.

Block Apps from Your Watch

- 1 On your watch, go to a card.
- 2 Swipe from right to left until you see .
- 3 Tap  >  to confirm.

Block Apps Using the Android Wear App


- 1 On your phone, open the **Android Wear**  app.
- 2 Tap  > **Block app notifications** > .
- 3 Select the app you want to block.

Call Notifications

You can get an instant alert when your phone receives an incoming call. The notification displays the caller's number or contact on your phone and lets you accept or decline the call.

NOTE

- The 'Play phone audio on watch' option is set as Off by default.
- If you set the 'Play phone audio on watch' option on in the Bluetooth Device menu in Settings, you will be able to receive call notifications, accept incoming calls, and make outgoing calls on your phone via your watch (**Settings > Bluetooth > Play phone audio on watch > ON**).



Swipe right to
answer a call

Incoming call
notification

Swipe left to
reject a call

Change When Notifications Arrive

You can change what notifications show up on your watch and when. To change the interruption settings, swipe down from the top of your watch's screen. You'll see a set of interruption options. Tap to select

None, **Priority only**, or **Show all**.

🚫: Turn off all interruptions.

★: Only allow priority interruptions.


🔔: Allow all interruptions.

🔧 NOTE

- Some content may differ from your device depending on the OS version.

See Remaining Battery or Date

Swipe down from the top of the screen.




🔧 NOTE

- Some content may differ from your device depending on the OS version.

Access the Sound Settings

Allows you to set the sound for notifications. You can also change to silent.

- Press the Sound icon .




Turn Your Screen Off Temporarily with Theater Mode

You can turn off your watch's screen so the display doesn't light up and notifications don't appear.

- Press the **Power Key** twice quickly.

OR


- 1 If your screen is dimmed, touch the screen to wake up the watch.
- 2 Swipe down from the top of the screen. Swipe from right to left until you see **Theater mode** . Tap the icon to turn it on.

Boost Screen Brightness Temporarily


You can turn up the brightness temporarily if you're outdoors in a sunny spot. The extra brightness will last for a few seconds and turn off automatically.

- Press the **Power Key** three times quickly.

OR

- 1 If your screen is dim, touch the screen to wake up the watch.
- 2 Swipe down from the top of the screen. Swipe from right to left until you see **Brightness Boost** . Tap the icon to turn it on.

Access the Settings Menu

- Press and hold the **Power Key** until the app list appears, then touch **Setting** .

OR



- Swipe left until the app list appears, then tap **Settings** .

Manage Storage

Through the **Android Wear**  app on your phone, you can see:

- How much storage space is available
- Total storage space on your watch
- Apps or services that are using your watch's storage

To See the Storage Details:

- 1 Make sure your watch is connected to your phone.
- 2 On your phone, open the **Android Wear**  app.
- 3 Tap  > Tap your watch's name if you have multiple devices > **Watch storage**.



Tasks Using Voice Command

You can see a menu of simple tasks on your watch, and anything in this list can also be said aloud. Just say “**OK Google**” or swipe the home screen to the left until you see the **Speak now** option, then say your command or question.

For example, once you’re on the **Speak now** menu, you can touch “**Start stopwatch**”. To do the same thing with your voice, just say “**OK Google, start stopwatch**” from most screens.

NOTE

- Some voice actions are not available in all languages and countries.

Follow These Steps to Start Using Your Voice on Your Watch:

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say “**OK Google**”. You will see the **Speak now** prompt.
- 3 Say your command or ask your question.

Opening a Feature Using the Power Key


- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 Press and hold the **Power Key** until the app list appears.
- 3 Swipe left until you see the **Speak now** prompt.
- 4 Swipe down to choose the task you want.

NOTE

- You’ll see recently used apps at the top of the list of things you can do.

Change the Apps You Use for Voice Actions

You can set which apps to use for different voice actions. For example, you can change the app you use for setting alarms or sending messages.

- 1 On your phone, open the **Android Wear**  app.
- 2 On the bottom half of the screen, a list of actions will be displayed.
- 3 Scroll and tap an action. You can choose from the available apps.

NOTE

- You can also download apps that work with Android Wear from the **Play Store**



Take or View a Note

You can speak to your watch to create a note or view existing notes using **QuickMemo+** or Android apps like **Google Keep**.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say “**OK Google**” or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say “**Take a note**”.
- 4 Speak your note when prompted. (e.g. “Try the new restaurant on Main Street”). Your note will automatically be saved after a few seconds. Touch the X if you want to cancel.
- 5 When you try this feature for the first time, related apps on your phone will appear on the watch (Ex. Google Keep, QuickMemo+). If you install two or more related apps on your phone, select the app you want to use, and it'll be shown starting next time by default.

 **NOTE: If you installed QuickMemo+ or Google Keep on your phone:**

- The app turns the words you speak into text. When you have finished speaking, your text note is saved to **QuickMemo+** or **Google Keep** on your mobile device.
- View and edit your notes by opening the app on your mobile device.

Set a Reminder

You can speak to your watch to set a reminder. Once you set a reminder, you'll see a card when your reminder goes off.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "OK Google" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Remind me**".
- 4 Complete your reminder when prompted. Your reminder will automatically save after a few seconds. Touch the **X** if you want to cancel.

Show Me My Steps

With this feature you can view a count of the steps you have taken today and review a log of steps taken over the last week, as measured by the Fit app.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "OK Google" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Show me my steps**". You will see your step count, progress to your fitness goal and a bar chart of your daily step counts.
- 4 View a list of your daily step totals by swiping up across the screen.

Show Me My Heart Rate

You can use the Heart Rate app to measure and record your current heart rate.

NOTE

- The device's heart rate measurement feature is not meant for clinical or medical diagnosis. Follow the guidelines in **Wearing the watch** and **Ensuring accurate measurements** to make sure your heart rate measurements are accurate.

Measuring Heart Rate

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "**OK Google**" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Show me my heart rate**".
- 4 Your watch will start measuring your heart rate. After a short period of time, you will see your heart rate on the screen along with your heart rate measurement history.
- 5 Take another measurement by tapping **Check again**.

Send a Text

This feature enables you to dictate text messages on your watch to contacts stored on your mobile device. You can also reply to any received text messages that appear in cards.

Sending a Message

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "OK Google" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Send a text**".
- 4 The **To whom?** screen will be displayed. You will see the **Speak now** prompt. Say the name of the contact you want to send a text message to. When the list appears, select the contact you want.
- 5 You will be prompted to say the message you want to send. Say your message or insert emoticons.
- 6 Your message will be sent automatically.

Replying to a Message

You will see cards if you get message notifications on your phone. Swipe from right to left until **Reply** appears. Tap **Reply**, then say your message.

Email

Your watch can be used to write and read emails from your mobile device.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say “**OK Google**” or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say “**Email**”.
- 4 The **To whom?** screen will be displayed. You will see the **Speak now** prompt.
- 5 Say the name of the contact you want to send an email to. When the list appears, select the contact you want.
- 6 You will be prompted to say the message you want to send.
- 7 Your message will be sent automatically.

Checking Emails on Your Phone

When reading emails on your watch, swipe the message card from right to left and tap **Open on phone**.

Replying to an Email

Swiping from right to left lets you take assorted actions, such as archive or reply. Tap **Reply** and say your message. Your message will be sent automatically.

Deleting Email Messages

Swipe the message card from right to left and tap **Delete**.

Agenda

You can view events scheduled on your mobile device's calendar using your watch.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say **"OK Google"** or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say **"Agenda"**. You will see a list of scheduled events.
- 4 Tap an event to view the event's details.

Navigate

You can find your way to a selected destination using the watch.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say **"OK Google"** or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say **"Navigate"**, followed by the location.

Set a Timer

The watch can be used as a countdown timer. Once you set a timer, you'll have a new card with the countdown.

- 1 If your screen is dim, tap the screen to wake up the watch.
- 2 From the watch face, say "**Ok Google**" or press and hold the **Power Key** until the apps list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Set a timer**".
- 4 Swipe through the available durations and start the timer by tapping the desired duration.
 - Start or resume the countdown by tapping ►.
 - Pause the timer by tapping ||.

Dismissing the Timer

When your timer goes off, dismiss it by swiping from left to right on your screen.

Use the Stopwatch

Measure how much time has passed with the Stopwatch app.


- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "**OK Google**" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "**Start stopwatch**".
- 4 Tap ► to start.

Set an Alarm

Multiple alarms can be set on your watch. Your watch and phone alarms are separate.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "OK Google" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "Set an alarm".
- 4 Find the desired alarm time by swiping up or down.

When an alarm goes off, your watch will vibrate and display a card.



Show Alarms

You can show and delete the alarms that you set.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch face, say "OK Google" or press and hold the **Power Key** until the app list appears, then swipe left. You will see the **Speak now** prompt.
- 3 Say "Show alarms".

A decorative graphic consisting of several groups of horizontal white lines of varying lengths, arranged in a descending staircase pattern from the top left towards the bottom right. The background is a solid red color.

Using Apps


The app list provides a list of the applications included on the watch.

To Reach the Apps Installed on Your Watch

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 Swipe left on the screen to open the apps list.

Downloading Other Apps






You can see a list of recommended apps in the **Play Store** .

Open the **Android Wear**  app to download more apps on your phone.

Phone

Making a Call

You can make and receive calls directly from your watch. Your watch can display the dialpad so you can dial a number.



- 1 Press and hold the **Power Key** until the apps list appears, then touch **Phone** .
- 2 Swipe left until the dialer appears.
- 3 Enter the number using the dialer. If you want to check the phone number that you entered, swipe down. Touch the  if you want to cancel and Touch the  to delete a digit.
- 4 After entering the desired number, tap  to place the call.
- 5 If you want to hang up the phone, then press the red button .

NOTE

- You can also make a call from the **Recent** list and **Contacts** list.
- When 'Play phone audio on watch' is set on the watch's Bluetooth settings (**Settings** > **Bluetooth** > **Play phone audio on watch** > **ON**), you can select between two options, "**Call from watch**" or "**Call from phone**". Touch "**Cancel call**" if you want to cancel.
- The 'Play phone audio on watch' option is set as Off by default.

Answering and Rejecting a Call

During an incoming call, you can answer or reject the call.


- Swipe  to the right to answer the call.
- Swipe  to the left to reject the call.

To View the Favorite contact list


You can see the favorite contact list from your watch as easily as on your phone.

- 1 Press and hold the **Power Key** until the apps list appears.
- 2 Swipe left until the favorite contact list appears.






Call Forwarding


This feature allows you to forward calls to your watch using **Call forwarding**  when incoming calls are not answered on your mobile phone.

How to activate call forwarding when paired to a GSM device

- 1 Press and hold the **Power Key** until the apps list appears, then touch **Settings** .
- 2 From the **Settings** menu, tap **Cellular** > **Call forwarding** > **Turn on** > **Request activation**.

How activate call forwarding when paired to a CDMA device

- 1 On your phone, download **LG Call forwarding**  from the **Play Store**  app and install it.
- 2 The mobile phone and watch must be turned on and connected for call forwarding to work correctly.
- 3 Open the **Call forwarding**  app on the watch.
- 4 Tap  to turn call forwarding on and forward calls to your watch. Tap  to turn it off.



NOTE

- You can also use the LG Call forwarding app to activate the feature while paired with a GSM device.

 **NOTE**

- Descriptions, screen images and supported languages in this guide may differ due to app updates.
- The call forwarding feature for your watch is not supported by all carriers. Please contact your service provider for supported features.



 **WARNING**

- Depending on your service provider, you may have to register for call forwarding service in advance.
- This feature may not work depending on network conditions. Please check with your service provider if you have any issues.
- For call forwarding service information, please check with your service provider.

Messenger



You can send and respond to messages directly for your watch.

Sending a Message

- 1 Press and hold the **Power Key** until the apps list appears, then touch Messenger .
- 2 Tap **New message**  and then select the contact you want to send the message.
- 3 You will be prompted to say the messages you want to send or select the message you want to send.
- 4 Your message will send automatically.

Replying to a Message

You get message notifications on your phone or watch. To see your phone SMS, install Messenger. With Messenger on your phone, you can reply to all your phone's conversations from your watch.



- 1 Press and hold the **Power Key** until the apps list appears, then touch Messenger .
- 2 Select the contact you want when the contact list appears if there are some messages you receive.
- 3 Tap  > **Reply**.
- 4 Speak a reply, draw emojis, or send a preset message.

NOTE

- To reply from a notification, swipe up on the notification, then swipe left until you see **Reply via SMS**.

LG Health

The LG Health app helps you manage your health and maintain good exercise habits by tracking logs and letting you compete with others.

- 1 Press and hold the **Power Key** until the app list appears, then tap **LG Health** .
- 2 To start using this app, enter your profile and tap .
- 3 Select the desired item. Use the options below to begin tracking your activity.
 - **Tracker:** Select an exercise type and intensity and record your exercise or receive coaching.
 - **Stress:** Receive messages about your stress index (step 4) and stepby-step guides. Fasten the watch to your wrist before use. (Keep it away from your wrist bone.)
 - **Settings:** Access LG Health options such as Profile, Goal unit, Daily goal, Units, Exercise notification, Tracker layout, and Delete data. View or edit the profile that you set on your first use. Delete data recorded in LG Health, such as Tracker logs and Stress logs.

NOTE

- This feature is provided for user convenience. Please use for reference only.

Use the Google Fit App

The Fit app lets you count steps and view how far you have walked. You can also see your heart rate measurements.

Installing the Google Fit app on the phone that your Android Wear watch is paired with lets you sync data between the two devices and enjoy all of Fit's features.

Press and hold the **Power Key** until the app list appears, then tap **Fit** ❤️. Swipe left to see details.

See Today's Step Estimate

Speak or use the menu to see an estimate of how many steps you've taken.

Say "OK Google". When you see the **Speak now** prompt, say "**Show me my steps**" (See **Show me my steps** section for more information).

OR

Open the **Fit** ❤️ app.

Check Your Heart Rate

Speak or use the menu to check your heart rate.

Say "OK Google". When you see the **Speak now** prompt, say "**Show me my heart rate**" (See **Show me my heart rate** section for more information).


OR

- 1 Open the **Fit** ❤️ app and swipe left until the Heart rate appears.
- 2 Swipe up to see your measurement history or tap ❤️ to measure your heart rate.




Settings

Launching the Settings Menu

- Press and hold the **Power Key** until the apps list appears, then touch **Settings** .

OR


- Swipe left until the apps list appears, then tap **Settings** .

Adjusting Display Brightness

The brightness of the watch display can be altered on the device itself.

- 1 From the **Settings** menu, tap **Adjust brightness**.
- 2 Choose a brightness level by touching an option.

Change Your Watch Face

You can change the design of your watch face in a few ways: by touching and holding the background of your watch's screen, through the **Android Wear**  app on your phone, or through the **Settings** menu on your watch.

- 1 From the **Settings** menu, tap **Change watch face**.
- 2 Swipe right and left to browse designs.
- 3 Tap to choose a new design.

Change the Font Size

You can set the size of the font displayed in the watch.

- 1 From the **Settings** menu, tap **Font size**.
- 2 Choose a size level by touching an option.

Gestures

You can use motion gestures to navigate notification cards, lists, and more.

- From the **Settings** menu, tap **Gestures** to turn on or off.
 - Flick your wrist out to scroll down a page.
 - Flick your wrist in to scroll up a page.
 - Push your arm down to select a card and open a new screen.
 - Pivot your arm up to go back.
 - Shake your wrist to exit to the watch face from any screen.

Screen On/Off Settings

You can set the screen to show the time or turn off completely when you're not using the watch. If turned off, the screen will turn on when you tilt it or cover the screen.

- From the **Settings** menu, tap **Always-on screen** to turn on or off.
 - **On:** A dimmed watch face is shown when your watch is idle.
 - **Off:** The watch screen darkens when idle.

Sound

This menu allows you to set various sound settings.

- From the **Settings** menu, tap **Sound**.

Wi-Fi

If Wi-Fi is set to Automatic mode, you can sync your watch and phone even when Bluetooth is not available. Wi-Fi is turned on automatically when Bluetooth is disconnected. When using a Wi-Fi connection, your watch can get notifications from your phone even if Bluetooth is unavailable. Your watch will search for and connect to the nearest Wi-Fi network based on the Wi-Fi list registered on your phone.

- From the **Settings** menu, tap **Wi-Fi** and set it to Automatic or Off.

Bluetooth Devices

Your watch automatically searches for Bluetooth devices within range. You can pair your watch with a headset in the Bluetooth devices menu within Settings. You can also unpair and disconnect headsets.

- From the **Settings** menu tap **Bluetooth devices**.

NOTE

- Only Bluetooth devices that support the A2DP and HFP profile are supported.
- You can only disconnect your watch from your phone via the Android Wear application on your phone.
- You can turn the call audio on and off in the watch's Bluetooth settings (**Settings** > **Bluetooth** > **Play phone audio on watch**).

Cellular

This menu allows you to configure various mobile network settings.

- From the **Settings** menu, tap **Cellular**.

Location

Manage location services to determine your approximate location.

- From the **Settings** menu, tap **Location** to turn it on or off.

NOTE

- When paired with a phone, the watch will use the location of the phone. To improve location accuracy when paired with a phone, enable High accurate in your phone's location settings.
- Turn on the location setting on your watch if you want use the location service when your watch is not paired with a phone.

Airplane Mode

When Airplane mode is on, you can use still many of the features on your watch (such as Heart Rate) when you are on an airplane or anywhere else where sending or receiving data is prohibited.

NOTE

- When in Airplane Mode, your watch cannot access information stored on your mobile device. You should also enable Airplane mode on your mobile device.
- From the **Settings** menu, tap **Airplane mode** to enable or disable.

Accessibility

Allows you to set accessibility settings.

- From the **Settings** menu, tap **Accessibility** to adjust the available options.

Date & Time

Allows you to set your preferences for how the date and time is displayed.

- From the **Settings** menu, tap **Date & time**.

Screen Lock

Set a pattern to draw with your finger that unlocks the screen.

- From the **Settings** menu, tap **Screen lock**.


Permissions

Allows you to control permissions for individual applications.


- From the **Settings** menu, tap **Permissions**.

Unpair with Phone

This setting unpairs the watch from your phone, resets your watch's settings to their factory default values, and deletes all of your data.

- 1 From the **Settings** menu, tap **Unpair with phone**. You are prompted to confirm.
- 2 Tap 
 - Your watch connects to one mobile device at a time.
 - Unpairing with your phone erases all data from your watch's memory. After completion, it is ready to connect to another mobile device.

Power Off

- 1 From the **Settings** menu, tap **Power off**.
- 2 When prompted with the message Are you sure?, tap .

About

Information about your watch is displayed here. You can view the Model, Device name, Software version, Serial number, Build number, Connection and Battery information. The following options are also available.

- From the **Settings** menu, tap **About**.
 - **System updates:** Check to see if the latest software is loaded on your watch.
 - **Regulatory information:** Displays regulatory information.
 - **Legal notices:** Instructs you to see your mobile device for legal notices.

More Information

Open Source Software Notice Information

To obtain source code contained in this product that is licensed under GPL, LGPL, MPL, and other open source licenses, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge to cover distribution costs (media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

Trademarks

- Copyright ©2016 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

Regulatory Information

- 1 Press and hold the Power Key until the app list appears.
- 2 Tap **Settings** > **About** > **Regulatory information**.

How to Update Your Device

Access to latest firmware releases, new software functions and improvements.

- 1 Press and hold the **Power Key** until the app list appears.
- 2 Tap **Settings** > **About** > **System updates** on your device.

