

Step 4: Activate your DVR Kit

Once it's paired with your Genie Lite receiver, you will need to activate your DVR kit. Sign in to your DIRECTV online account and visit directv.com/activate.

You can also call Customer Care at:
800-531-5000

Problems Connecting?

If you followed Steps 1-3 above, and your receiver does not display the "Genie Lite HD DVR Kit Found" screen, call Customer Care at 800-531-5000 for assistance.



Get Connected

Once your Genie Lite HD DVR Kit is connected and working, make sure your receiver is connected to the Internet to take full advantage of everything DIRECTV has to offer.

Get connected so you can:

- Access thousands of On Demand movies and shows*
- Order DIRECTV CINEMA® movies
- Enjoy TV Apps such as ScoreGuide™, Weather, and other interactive features
- Listen to Pandora Internet Radio, right on your TV

Visit directv.com/getconnected for details.

*Additional fees required for new releases.

DIRECTV services not available outside the U.S. DIRECTV programming is available separately and independently of DIRECTV equipment.

A valid programming subscription is required to operate DIRECTV equipment. Activate your DIRECTV programming today at 1.800.DIRECTV (1.800.347.3288). The DIRECTV Genie Lite HD DVR Kit requires DIRECTV Advanced Receiver Service or DVR + Whole-Home DVR Service, and is intended for use only with a DIRECTV Genie Lite Receiver (model # H44). Visit www.directv.com/genielite for more information.

Additional equipment charges may apply for each DIRECTV Genie Lite HD DVR Kit. You must activate each new/additional or reactivated DVR kit on your existing account by calling DIRECTV Customer Care at 1-800-531-5000. © 2015 DIRECTV, LLC. DIRECTV and the Cyclone Design logo, and DIRECTV Genie and the Genie logo are trademarks of DIRECTV, LLC.

PN 100768638B 08/15



GenieLiteHDDVRKitv1.2July082015

genie™

**DIRECTV Genie® Lite HD DVR Kit
Quick-Start Guide**



Genie Lite HD DVR Kit: All the Fun & Benefits of a Full DVR

Welcome to your new Genie Lite HD DVR Kit! Follow the simple steps in this guide to connect your DVR kit and turn your Genie Lite Receiver into a fully functioning DVR.*

Soon you'll be able to:

- Record and playback your favorite shows, including entire seasons**
- Pause, rewind and fast forward live TV
- Stream programs on your mobile devices
- Use DIRECTV™ Voice†
- Record up to five shows at once
- And much more!

* DIRECTV DVR Service (Advanced Receiver Service, or DVR + Whole-Home DVR Service) required.

** Must have the hard drive connected to receiver at all times for continuous Season Record.

† Requires a smart phone with the DIRECTV Mobile App installed. "On TV" requires an Internet-connected Genie Lite. Visit directv.com/voice for a complete list of phones and operating system versions supported.

Getting Started

Step 1: Connect the DVR Kit

Connect one end of the supplied eSATAp cable to the port on the back of the Genie Lite HD DVR Kit.

Step 2:

Connect the DVR Kit to your Genie Lite
Connect the other end of the cable to the port labeled "HARD DRIVE" on the back of the Genie Lite Receiver. Check to ensure that all connections are secure.

Step 3:

Pair the DVR Kit to your Genie Lite
Next, you'll need to pair your DVR kit with your Genie Lite Receiver. Follow the onscreen instructions that display on your TV*. Your Genie Lite will restart once it's ready to format the DVR kit and finish the pairing process.



* The pairing process starts with a screen that states: "Genie Lite HD DVR Kit Found. Restart Required."