



Having trouble?

No TV or Internet:




Check your connections:

Cables usually make an audible click when secure.




Check Power: Power light on the Wi-Fi Gateway should be green; if not, try another electrical outlet.

Check Service light on front of the Wi-Fi Gateway: If after 5 minutes the light is red or off, power down the Wi-Fi Gateway by holding down red Reset button for 15 seconds.



TV receivers not responding:

Confirm Service light is solid green on the Wi-Fi Gateway. If so, hold the TV receiver's Power button down for 10 seconds and release, then wait five minutes.



If your existing Wi-Fi settings did not transfer, you will need to set up a new Wi-Fi Network Name and Password. To do so, follow these steps:

- Use settings from new Wi-Fi Gateway yellow sticker
- Open your device's Wi-Fi connection settings, select your Wi-Fi Network Name, and enter Wi-Fi Password to connect
- Record and keep your Wi-Fi settings for future reference when connecting all your Wi-Fi devices

Wi-Fi Network Name: ATTXXXXXXX

Wi-Fi Password: XXXXXXXXXXXXX

For help, att.com/support

AT&T Internet Wi-Fi Gateway Replacement

self-
installation
guide



Wi-Fi Gateway Power light is amber: Don't worry. This is a normal part of the power-up sequence.

Additional assistance: Call 800.288.2020 and ask for "technical support."

Additional information

Test your Internet connection speed:

Our speed test takes less than a minute to perform two key measurements (Download and Upload) to help you determine if you should take steps to improve the performance of your online experience. Visit att.com/speedtest

Manage your account:

Available 24/7, download the myAT&T app at att.com/myattapp from your mobile device.

Repair Center:

Phone: 800.246.8464

IPv6

AT&T supports IPv6 across our network, equipment, and devices. Visit att.com/ipv6 for more information.

¿Hablas español?

Para ver a esta guía en español, visita att.com/guías y haz clic en la pestaña Internet. Desplázate hacia abajo a donde dice "Guías de Reemplazo" y elije ATT150150902-4.

Accessibility support:

- Alternate formats now available in large print or braille. Call 800.288.2020 and request your guide number (ATT150150902-4).
- Telephone equipment for visual and/or hearing impaired:
 - Phone: 877.902.6350
 - TTY: 800.772.2889
- Repair Center:
 - Phone: 800.246.8464
 - TTY: 800.397.3172
- Accessible Tagged PDF: Visit att.com/userguides to find this guide (UV Pace 5268 without Voice Swap Guide).
- Device Compatibility Feature: Compatible with any TTY/TDD devices with standard phone line.

Need more help?

Visit att.com/support


Call us at **800.288.2020** and ask for "technical support."

Get started

Approximate installation time: 40 minutes

These instructions will guide you through the process of replacing your Wi-Fi Gateway.

In the box:



Wi-Fi Gateway
(front view)



Power Cord
(2 parts)




1. Set up

Approximate time: 15 minutes

! Please note that your U-verse TV and Internet services will not operate during this process. This includes recording TV shows.

- A.**
 - Unplug power cord from existing Wi-Fi Gateway
 - Set power cord aside
 - Stand new Wi-Fi Gateway side by side with existing Wi-Fi Gateway
- B.**
 - Transfer one connection at a time from the existing Wi-Fi Gateway to new Wi-Fi Gateway
- C.**
 - Remove yellow sticker covering the Power port of new Wi-Fi Gateway
 - Connect new power cord to Power port of new Wi-Fi Gateway and plug into an electrical outlet

Below is a completed setup. Your existing Wi-Fi Gateway and connections may vary.




2. Power up

Approximate time: 10–15 minutes

! Your Wi-Fi Gateway is now powering up. During this time (up to 15 minutes), do not unplug the power cord or the green data cable, as this can permanently damage the Wi-Fi Gateway and significantly delay your service activation.

When complete, the Service light will turn solid green for at least a minute. If the Service light does not turn solid green or continues to blink after 15 minutes, see **Having trouble?** on the back of this guide.

NOTE: Your TV may take a few minutes to display. Check your TV for service. If your TV does not respond, refer to **Having trouble?** on the back of this guide.



New Wi-Fi Gateway indicator lights on front panel. Lights may vary with setup.

3. Go Wi-Fi

Approximate time: 10 minutes

New Wi-Fi setup:

A. Select only one option to begin the Wi-Fi setup.

Option 1: Connect using PC

- Connect laptop or PC with an Ethernet cable to your Wi-Fi Gateway
- Continue to **B**

Option 2: Connect using smartphone/tablet

- Establish a temporary connection using new Wi-Fi settings located on yellow sticker on new Wi-Fi Gateway
- Open your device's Wi-Fi connection settings and select your Wi-Fi Network Name and enter your Wi-Fi Password to connect to your network
- Continue to **B**

B.

NOTE: Please wait up to 10 minutes for the Wi-Fi Gateway to complete the power up process before attempting to restore your settings.

- Open a browser and go to ufix.att.com/restore
- Log in to your account. If you forgot your User ID (primary AT&T email address) and Password, help can be found on the account log-in screen.
- Follow the onscreen instructions to transfer the existing Wi-Fi settings.
- Record existing Network Name and Wi-Fi Password on separate yellow sticker from kit.
- Place new yellow sticker over your new Wi-Fi Gateway's yellow sticker.

! **NOTE:** If you receive a "We were unable to restore your Wi-Fi Settings" message, the transfer may still be in progress. Wait another 5–10 minutes to check your Wi-Fi connection to the network in case your settings were restored.

! **NOTE:** Any custom settings made for security cameras, game consoles, etc., on your original Wi-Fi Gateway will also need to be made on your new Wi-Fi Gateway.

4. Easy return

(Refer to return instructions in your kit.)

- A.** Return your equipment at no cost to you within 21 days to avoid \$150 charge.
- B.** Take original Wi-Fi Gateway and power cord to nearest The UPS Store. Bring your AT&T account number located on your packing slip. Please do not return other devices.
- C.** UPS will scan your equipment, provide a receipt, pack, and ship equipment to AT&T at no cost to you.

