


All-Fi Hub (CGW450)

AT&T **All-Fi**



LED Display

Notification Light

















What Do The Lights Mean?


Complete guide to the information the LED lights on your AT&T All-Fi™ Hub provide.

Display & Notification Light

All-Fi Hub Display	Notification Light	Color	Meaning
Off		Pulse White	Your All-Fi Hub is starting up. Expect to see the AT&T logo before the hub proceeds with checking for signal.
		Off	The All-Fi Hub is searching for the best signal tower for your service. Please standby.
		Off	The All-Fi Hub has found a signal tower and is performing a signal quality check. Please standby for the results to display.
		Solid Green	You have an excellent signal. Your All-Fi Hub display will show your signal strength and upload/download speeds.
		Solid Yellow	You have a good signal. Your All-Fi Hub display will show your signal strength and upload/download speeds.
		Solid Red	You have a poor signal. You may need to move the All-Fi Hub to a better location.
		Off	The All-Fi Hub displays the upload and download speeds of your Internet Air Service after a signal quality check.
		Off	The All-Fi Hub displays if you have 5G or LTE coverage. Seeing either means you can expect speeds up to 100Mbps.

Display & Notification Light

All-Fi Hub Display	Notification Light	Color	Meaning
		Off	Off with clock during set up: Make sure you have completed your registration and set up with Smart Home Manager. Off with clock: This means your hub is working correctly.
		Solid Blue	Basic Security (Shield Logo)
		Pulsing Amber	Your All-Fi Hub is receiving an update. Please wait until it displays a clock and you'll be back online.
		Pulsing Red	Two or more devices attempted to WPS pair to the All-Fi Hub. Please wait and try with one device at a time.
		Solid Red	Your All-Fi Hub displays error codes with an E followed by a string of numbers. Check the Internet Air error codes FAQ to find out what the error code on your Hub means and how to fix it.
		Off	Your All-Fi Hub is going through a factory reset. Please wait while it starts back up.
		Off	Your All-Fi Hub displays a short Cuckoo clock animation at 12:00pm.
		Off	Your All-Fi Hub displays an AT&T animation at several points while booting up after plugging in power or pressing the red reset button.












WPS
Button LED

Power Jack
LED

1G
Ethernet
Port LED

10G
Ethernet
Port LED

WPS LED (back of hub)

All-Fi Hub Display	Notification Light	WPS Light	Color	Meaning
			Blinking Green	The WPS button has been pressed. Please take action on the Wi-Fi device you are attempting to connect to the gateway.
			Solid Green	WPS Pairing is successful.
			Solid Red	Attempt to connect your Wi-Fi devices using WPS has failed. Please wait until the light changes and then press the WPS button to try again